

POWERTECH[™] **2.9 L**
OEM Diesel
Engines

OPERATOR'S MANUAL
POWERTECH **2.9 L OEM Diesel**
Engines

OMRG27897 Issue (01JUN06) (ENGLISH)

CALIFORNIA
Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

If this product contains a gasoline engine:

 **WARNING**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

The State of California requires the above two warnings.

Introduction

Foreword

THIS MANUAL CONTAINS INFORMATION to operate and service the following engines:

Saran-built (France) Emission Non-Certified Engines:

- CD3029DF120
- CD3029DF121
- CD3029DF122
- CD3029DF123
- CD3029DF124
- CD3029DF160
- CD3029DF161
- CD3029DF162
- CD3029DF163
- CD3029DF164
- CD3029DF165
- CD3029TF120
- CD3029TF121
- CD3029TF123
- CD3029TF160
- CD3029TF161
- CD3029TF162
- CD3029TF163

Saran-built (France) Tier I Emission Certified Engines:

- CD3029DF150
- CD3029DF151
- CD3029DF152
- CD3029DF180
- CD3029TF150
- CD3029TF152
- CD3029TF180

Saran-built (France) Tier II Emission Certified Engines:

- CD3029TF270

Torreón-built (Mexico) Emission Non-Certified Engines:

- PE3029DF120
- PE3029TF120

Torreón-built (Mexico) Tier I Emission Certified Engines:

- PE3029DF150
- PE3029TF150

Torreón-built (Mexico) Tier II Emission Certified Engines:

- PE3029TF270

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS IN THIS MANUAL are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

WRITE ENGINE SERIAL NUMBERS and option codes in the spaces indicated in the Record Keeping Section. Accurately record all the numbers. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the engine.

SETTING FUEL DELIVERY beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this engine.

CERTAIN ENGINE ACCESSORIES such as radiator, air cleaner, and instruments are optional equipment on John Deere OEM Engines. These accessories may be provided by the equipment manufacturer instead of John Deere. This operator's manual applies only to the engine and those options available through the John Deere distribution network.

Engine Owner

John Deere Engine Owner:

Don't wait until you need warranty or other service to meet your local John Deere Engine Distributor or Service Dealer. To register your engine for warranty via the Internet, use the following URL:

<http://www.johndeere.com/enginewarranty>

Learn who he is and where he is. At your first convenience, go meet him. He'll want to get to know you and to learn what your needs might be.

Aux Utilisateurs De Moteurs John Deere:

N'attendez pas d'être obligé d'avoir recours à votre concessionnaire John Deere ou au point de service le plus proche pour vous adresser à lui. Pour enregistrer votre moteur pour la garantie via Internet, utilisez l'adresse suivante:

<http://www.johndeere.com/enginewarranty>

Renseignez-vous dès que possible pour l'identifier et le localiser. A la première occasion, prenez contact avec lui et faites-vous connaître. Il sera lui aussi heureux de faire votre connaissance et de vous proposer ses services le moment venu.

An Den Besitzer Des John Deere Motors:

Warten Sie nicht auf einen evt. Reparaturfall, um den nächstgelegenen John Deere Händler kennen zu lernen. Zur Registrierung Ihres Motors für die Garantie dient folgende Internet-Adresse:

<http://www.johndeere.com/enginewarranty>

Machen Sie sich bei ihm bekannt und nutzen Sie sein "Service Angebot".

Proprietario del motore John Deere:

Non aspetti fino al momento di far valere la garanzia o di chiedere assistenza per fare la conoscenza del

distributore dei motori John Deere o del concessionario che fornisce l'assistenza tecnica. Per registrare via Internet la garanzia del suo motore, si colleghi al seguente sito URL:
<http://www.johndeere.com/enginewarranty>

Lo identifichi e si informi sulla sua ubicazione. Alla prima occasione utile lo contatti. Egli desidera fare la sua conoscenza e capire quali potrebbero essere le sue necessità.

Propietario De Equipo John Deere:

No espere hasta necesitar servicio de garantía o de otro tipo para conocer a su Distribuidor de Motores John Deere o al Concesionario de Servicio. Registre su motor para la garantía en la siguiente dirección de internet: <http://www.johndeere.com/enginewarranty>

Entérese de quién es, y dónde está situado. Cuando tenga un momento, vaya a visitarlo. A él le gustará conocerlo, y saber cuáles podrían ser sus necesidades.

Till ägare av John Deere motorer:

Ta reda på vem din återförsäljare är och besök honom så snart tillfälle ges. Vänta inte tills det är dags för service eller eventuellt garantiarbete. Din motor garantiregistrerar Du via Internet på <http://www.johndeere.com/enginewarranty>

Din återförsäljare vill mycket gärna träffa dig för att lära känna dina behov och hur bäst han kan hjälpa dig.

Identification Views—Tier I Emission Certified Engines



3029D Right Front View

RG9173 -UN-29NOV00



3029D Left Front View

RG9172 -UN-29NOV00

RG.RG34710,4501 -19-14FEB03-1/2



3029T Right Front View

RG9175 -UN-29NOV00




3029T Left Front View

RG9174 -UN-29NOV00


RG.RG34710,4501 -19-14FEB03-2/2

Identification Views—Tier II Emission Certified Engines



3029TF270 Right Front View

RG12834 -UN-05MAR03



3029TF270 Left Front View

RG12835 -UN-05MAR03

OUOD005,00001D6 -19-14FEB03-1/1

Contents

| | Page | | Page |
|--|-------|--|-------|
| Record Keeping | | Warming Engine | 15-17 |
| Engine Serial Number Plate | 01-1 | Changing Engine Speed-Standard (Mechanical) Governor | 15-18 |
| Record Engine Serial Number | 01-1 | Idling Engine | 15-18 |
| Engine Option Codes | 01-2 | Stopping the Engine | 15-19 |
| Record Fuel Injection Pump Model Number | 01-4 | Using a Booster Battery or Charger | 15-21 |
| Safety | 05-1 | Lubrication and Maintenance | |
| Fuels, Lubricants, and Coolant | | Observe Service Intervals | 20-1 |
| Diesel Fuel | 10-1 | Use Correct Fuels, Lubricants, and Coolant | 20-2 |
| Lubricity of Diesel Fuel | 10-1 | Lubrication and Maintenance Service Interval - Prime Power Engines | 20-3 |
| Handling and Storing Diesel Fuel | 10-2 | Lubrication and Maintenance Service Interval - Standby Power | 20-5 |
| Testing Diesel Fuel | 10-2 | Lubrication & Maintenance/Daily | |
| Bio-Diesel Fuel | 10-3 | Daily Prestarting Checks | 25-1 |
| Aviation (Jet) Fuels | 10-4 | Lubrication & Maintenance/250 Hour/6 Month | |
| Burner Fuels | 10-4 | Servicing Fire Extinguisher | 30-1 |
| Minimizing the Effect of Cold Weather on Diesel Engines | 10-5 | Lubricating PTO Clutch Shaft Bearings | 30-1 |
| Diesel Engine Break-In Oil | 10-6 | Servicing Battery | 30-2 |
| Diesel Engine Oil | 10-7 | Changing Engine Oil And Replacing Oil Filter-All Except 3029TF270 Engines | 30-4 |
| Mixing of Lubricants | 10-8 | Checking Fan and Alternator V-Belt Tension . . . | 30-6 |
| OILSCAN™and COOLSCAN™ | 10-9 | Checking PTO Clutch Adjustment | 30-9 |
| Alternative and Synthetic Lubricants | 10-9 | Checking Engine Mounts | 30-10 |
| Lubricant Storage | 10-10 | Lubrication & Maintenance/500 Hour/12 Month | |
| Grease | 10-10 | Changing Engine Oil And Replacing Oil Filter—3029TF270 Engines Only | 35-1 |
| Diesel Engine Coolant | 10-11 | Lubricating PTO Clutch Internal Levers and Linkage | 35-4 |
| Additional Information About Diesel Engine Coolants and Supplemental Coolant Additives | 10-13 | Cleaning Crankcase Vent Tube | 35-4 |
| Testing Diesel Engine Coolant | 10-14 | Checking Air Intake System | 35-5 |
| Supplemental Coolant Additives | 10-15 | Replacing Fuel Filter Element | 35-6 |
| Operating in Warm Temperature Climates | 10-15 | Checking Cooling System | 35-8 |
| Disposing of Coolant | 10-16 | Testing Diesel Engine Coolant | 35-9 |
| Engine Operating Guidelines | | Replenishing Supplemental Coolant Additives (SCAs) Between Coolant Changes | 35-10 |
| Instrument (Gauge) Panels | 15-1 | | |
| Auxiliary Gear Drive Limitations | 15-9 | | |
| Generator Sets (Standby) Applications | 15-9 | | |
| Starting the Engine | 15-9 | | |
| Break-In Service | 15-12 | | |
| After Break-In Service | 15-14 | | |
| Normal Engine Operation | 15-15 | | |
| Cold Weather Operation | 15-16 | | |

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2006
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright © 1998, 2001, 2003

| Page | Page | |
|---|-------|--|
| Pressure Testing Cooling System | 35-12 | Lubrication and Maintenance Records |
| Checking and Adjusting Engine Speeds | 35-14 | |
| Lubrication&Maintenance/2000 Hour/24 Month | | Daily (Prestaring) Service |
| Adjusting Variable Speed on Generator Set | | Service, 250 Hour/6 Month |
| Engines. | 40-1 | Service, 500 Hour/12 Month |
| Checking and Adjusting Engine Valve | | Service, 2000 Hour/24 Month |
| Clearance | 40-2 | Service as Required |
| Flushing and Refilling Cooling System | 40-4 | Emission System Warranty |
| Testing Thermostat Opening Temperature | 40-7 | Emissions Control System Certification Label . . . |
| | | U.S. Emissions Control Warranty Statement. . . . |
| Service As Required | | |
| Additional Service Information | 45-1 | |
| Do Not Modify Fuel System | 45-1 | |
| Adding Coolant. | 45-2 | |
| Bleeding the Fuel System. | 45-3 | |
| Replacing Air Cleaner Filter Elements | 45-6 | |
| Inspecting Primary Filter Element | 45-8 | |
| Cleaning Primary Filter Element | 45-8 | |
| Element Storage. | 45-9 | |
| Replace Fan and Alternator Belts | 45-9 | |
| Inspecting Power Take-Off (PTO) Clutch | 45-10 | |
| Checking Fuses | 45-11 | |
| Troubleshooting | | |
| General Troubleshooting Information | 50-1 | |
| North American Wiring Diagram | 50-2 | |
| Engine Troubleshooting | 50-4 | |
| Electrical Troubleshooting. | 50-12 | |
| Lubrication System Troubleshooting | 50-14 | |
| Cooling System Troubleshooting | 50-16 | |
| Air Intake Troubleshooting | 50-18 | |
| Storage | | |
| Engine Storage Guidelines | 55-1 | |
| Preparing Engine for Long Term Storage | 55-2 | |
| Removing Engine from Long Term Storage | 55-3 | |
| Specifications | | |
| General OEM Engine Specifications | 60-1 | |
| Engine Power and Speed | | |
| Specifications-Tier I Emission Certified | | |
| Engines. | 60-3 | |
| Engine Power and Speed | | |
| Specifications-Tier II Emission Certified | | |
| Engines. | 60-4 | |
| Engine Power and Speed | | |
| Specifications-Emission Non-Certified | | |
| Engines. | 60-5 | |
| Engine Crankcase Oil Fill Quantities | 60-7 | |
| Unified Inch Bolt and Screw Torque Values | 60-10 | |
| Metric Bolt and Screw Torque Values. | 60-11 | |

Record Keeping


Engine Serial Number Plate

Each engine has a 13-digit John Deere engine serial number. The first two digits identify the factory that produced the engine:

- “CD” indicates the engine was built in Saran, France
- “PE” indicates the engine was built in Torreon, Mexico

Your engine’s serial number plate (A) is located on the right-hand side of cylinder block near the starter motor.

A—Serial Number Plate



Engine Serial Number Plate Location

RG.RG34710,5002 -19-30JAN98-1/1

Record Engine Serial Number

Record all of the numbers and letters found on your engine serial number plate in the spaces provided below.

This information is very important for repair parts or warranty information.


Engine Serial Number (A)

Engine Application Data (B)

Coefficient of Absorption Value (For Smoke Emissions) (C) (Earlier Saran-Built Engines Only)

NOTE: Tier II emission-certified engines have application data (B) ending in “270s”, while Tier I emission certified engines have data ending in “150s” (as illustrated) or “180s”, and emission non-certified engines have application data ending in “120s” or “160s”.

- A—Serial Number
- B—Application Data
- C—Coefficient of Absorption Value



Saran Serial Number Plate

RG11523 -UN-01DEC00




Torreon Serial Number Plate

RG11524 -UN-01DEC00

OURGP11,000000D -19-23MAY06-1/1

Engine Option Codes



Option Code Label

A—Base Code

OEM engines have an engine option code label affixed to the rocker arm cover. These codes indicate which of the engine options were installed on your engine at the factory. When in need of parts or service, furnish your authorized servicing dealer or engine distributor with these numbers.

The engine option code label includes an engine base code (A). This base code must also be recorded along with the option codes. At times it will be necessary to furnish this base code to differentiate two identical option codes for the same engine model.

The first two digits of each code identify a specific group, such as alternators. The last two digits of each code identify one specific option provided on your engine, such as a 12-volt, 55-amp alternator.

If an engine is ordered without a particular component, the last two digits of that functional group option code will be 99, 00, or XX. The following list shows only the first two digits of the code numbers. For future reference such as ordering repair parts, it is important to have these code numbers available. To ensure this availability, enter the third and fourth digits shown on your engine option code label in the spaces provided on the following page.

An additional option code label may also be delivered (in a plastic bag attached to the engine or inserted in the machine documentation). It is recommended to place this label either on this page of the operators manual or in the Engine Owner's Warranty booklet under Option Codes.

The machine manufacturer may have placed the label in a specific accessible area (inside the enclosure or close to a maintenance area).

Your engine option code label may not contain all option codes if an option has been added after the engine left the producing factory.

If option code label is lost or destroyed, consult your servicing dealer or engine distributor selling the engine for a replacement.

Record your engine Base Code (A) in the spaces provided below for easy reference.

Engine Base Code (A):

Record Keeping

| Option Codes | Description | Option Codes | Description |
|--------------|-----------------------------------|--------------|---|
| 11_____ | Rocker Arm Cover | 51_____ | Cylinder Head |
| 12_____ | Oil Filter Inlet | 52_____ | Gear-Driven Auxiliary Drive |
| 13_____ | Crankshaft Pulley/Damper | 53_____ | Fuel Heater |
| 14_____ | Flywheel Housing | 55_____ | Transport Skid/Shipping Stand |
| 15_____ | Flywheel | 56_____ | Paint |
| 16_____ | Fuel Injection System | 57_____ | Coolant Pump Inlet |
| 17_____ | Air Intake | 59_____ | Oil Cooler and Filter |
| 18_____ | Air Cleaner | 60_____ | Add-On Auxiliary Drive Pulley |
| 19_____ | Oil Pan | 62_____ | Alternator Mounting |
| 20_____ | Coolant Pump | 63_____ | Low Pressure Fuel Line |
| 21_____ | Thermostat Cover | 64_____ | Exhaust Elbow |
| 22_____ | Thermostats | 65_____ | Turbocharger |
| 23_____ | Fan Drive | 66_____ | Coolant Temperature Sensor/Switch |
| 24_____ | Fan Belts | 67_____ | Electronic Sensors (Base Engine) |
| 25_____ | Fan | 68_____ | Crankshaft Rear Damper |
| 26_____ | Engine Coolant Heater | 69_____ | Engine Serial Number Plate |
| 27_____ | Radiator/Heat Exchanger | 71_____ | Engine Oil Bypass Filter |
| 28_____ | Exhaust System | 72_____ | Electronic Software (in ECU)- Engine Performance |
| 29_____ | Ventilator System | 74_____ | Air Conditioning (A/C) Compressor (Optional) |
| 30_____ | Starter Motor | 75_____ | Air Restriction Indicator |
| 31_____ | Alternator | 76_____ | Oil Pressure Sensor/Switch |
| 32_____ | Instrument Panel | 77_____ | Timing Gear Cover |
| 33_____ | Tachometer | 78_____ | Air Compressor (Optional) |
| 35_____ | Fuel Filter | 79_____ | Engine Certification |
| 36_____ | Front Plate | 80_____ | Sea Water Pump |
| 37_____ | Fuel Transfer Pump | 81_____ | Primary Fuel Filter and Water Separator |
| 38_____ | Operator's Manual | 83_____ | Electronic Software (in ECU)- Vehicle Performance |
| 39_____ | Outlet Manifold | 84_____ | Electrical Wiring Harness |
| 40_____ | Oil Dipstick | 86_____ | Fan Pulley |
| 41_____ | Belt-Driven Front Auxiliary Drive | 87_____ | Belt Tensioner |
| 43_____ | Starting Aid | 88_____ | Oil Filter |
| 44_____ | Electronic Speed Sensor | 92_____ | Accessories (Factory Installed)(Rear PTO) |
| 45_____ | Balancer Shafts | 93_____ | Emissions Label |
| 46_____ | Cylinder Block | 95_____ | Special Equipment (Factory Installed) |
| 47_____ | Crankshaft | 96_____ | Wiring Harness |
| 48_____ | Pistons and Connecting Rods | 97_____ | Special Equipment (Field Installed) |
| 49_____ | Rocker Arm Assembly | 98_____ | Engine Lift Straps and Trim |
| 50_____ | Oil Pump | 99_____ | Service Kits |

NOTE: This is a complete option code list based on the latest information available at the time of publication. The right is reserved to make

changes at any time without notice. Your engine will not contain all option codes listed.

RG, RG34710, 5004 -19-11FEB03-2/2

Record Fuel Injection Pump Model Number


Record the fuel injection pump model and serial information found on the serial number plate (A).

Model No. _____ RPM _____

Manufacturer's No. _____

Serial No. _____

A—Serial Number Plate



RG11526 -UN-01DEC00

Injection Pump Serial Number Plate

RG, RG34710, 5005 -19-30JAN98-1/1

Safety

Recognize Safety Information

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-29SEP98-1/1

TS1389 -UN-07DEC88

Understand Signal Words

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



▲ WARNING

▲ CAUTION

DX,SIGNAL -19-03MAR93-1/1

TS187 -19-30SEP88

Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.




DX,READ -19-03MAR93-1/1

TS201 -UN-23AUG88

Replace Safety Signs

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



DX,SIGNS1 -19-04JUN90-1/1

TS201 -UN-23AUG88

Prevent Bypass Starting

Avoid possible injury or death from engine runaway.

Do not start engine by shorting across starter terminal. Engine will start with PTO engaged if normal circuitry is bypassed.

Start engine only from operator's station with PTO disengaged or in neutral.



Prevent Bypass Starting

OUOD013,0000001 -19-28NOV00-1/1

RG5419 -UN-28FEB89

Handle Fuel Safely—Avoid Fires

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



DX,FIRE1 -19-03MAR93-1/1


TS202 -UN-23AUG88

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

DX,FIRE2 -19-03MAR93-1/1

Handle Starting Fluid Safely

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.



TS1356 -UN-18MAR92

DX,FIRE3 -19-16APR92-1/1

Handle Fluids Safely—Avoid Fires

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.




TS227 -UN-23AUG88

DX,FLAME -19-29SEP98-1/1

Service Machines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



TS228 -UN-23AUG88

DX,LOOSE -19-04JUN90-1/1


Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 -UN-23AUG88

DX,WEAR -19-10SEP90-1/1

Protect Against Noise

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



TS207 -UN-23AUG88

DX,NOISE -19-03MAR93-1/1


Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93-1/1

Stay Clear of Rotating Drivelines

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.



TS1644 -UN-22AUG95

DX,PTO -19-12SEP95-1/1

Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.




TS218 -UN-23AUG88

DX,SERV -19-17FEB99-1/1

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area



TS220 -UN-23AUG88

DX,AIR -19-17FEB99-1/1


Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



X9811 -UN-23AUG88

DX,FLUID -19-03MAR93-1/1

Avoid Heating Near Pressurized Fluid Lines

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can accidentally burst when heat goes beyond the immediate flame area.




TS953 -UN-15MAY90

DX,TORCH -19-10DEC04-1/1

Use Proper Lifting Equipment

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



TS226 -UN-23AUG88

DX,LIFT -19-04JUN90-1/1

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.

Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.



TS220 -UN-23AUG88

DX,PAINT -19-24JUL02-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.




TS281 -UN-23AUG88

DX,RCAP -19-04JUN90-1/1

Install Fan Guards

Rotating cooling system fans can cause serious injury.

Keep fan guards in place at all times during engine operation. Wear close fitting clothes. Stop the engine and be sure fan is stopped before making adjustments or connections, or cleaning near the front of the engine.



Rotating Fan


TS677 -JUN-21/SEP89

OUQD006,000009D -19-07MAR03-1/1

Avoid Hot Parts

Avoid skin contact with exhaust manifolds, turbochargers and mufflers. Keep flammable materials clear of the turbocharger.

External dry exhaust parts become very hot during operation. Turbochargers and exhaust manifolds may reach temperatures as high as 600°C (1112°F) under full load. This may ignite paper, cloth or wooden materials. Parts on engines that have been at full load and reduced to no load idle will maintain approximately 150°C (302°F).



Hot Surface

TS271 -JUN-23/AUG88

OURGP12,0000135 -19-19JUL05-1/1


Avoid Harmful Asbestos Dust

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.



TS220 -JUN-23AUG88

DX,DUST -19-15MAR91-1/1

Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 -JUN-23AUG88

DX,SPARKS -19-03MAR93-1/1

Prevent Acid Burns

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



TS203 -JUN-23AUG88

DX,POISON -19-21APR93-1/1

Protect Against High Pressure Spray

Spray from high pressure nozzles can penetrate the skin and cause serious injury. Keep spray from contacting hands or body.

If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



TS1343 -JUN-18MAR92

DX,SPRAY -19-16APR92-1/1

Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



TS779 -JN-08NOV89

DX,REPAIR -19-17FEB99-1/1

Dispose of Waste Properly


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -JN-26NOV90

DX,DRAIN -19-03MAR93-1/1

Fuels, Lubricants, and Coolant

Diesel Fuel

Consult your local fuel distributor for properties of the diesel fuel available in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to EN 590 or ASTM D975 are recommended.

Required fuel properties

In all cases, the fuel shall meet the following properties:

Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below -20°C (-4°F) or elevations above 1500 m (5000 ft).

Cold Filter Plugging Point (CFPP) below the expected low temperature OR **Cloud Point** at least 5°C (9°F) below the expected low temperature.

Fuel lubricity should pass a minimum level of 3100 grams as measured by ASTM D6078 or maximum

scar diameter of 0.45 mm as measured by ASTM D6079 or ISO 12156-1.

Sulfur content:

- Diesel fuel quality and fuel sulfur content must comply with all existing emissions regulations for the area in which the engine operates.
- Use of diesel fuel with sulfur content less than 0.10% (1000 ppm) is **STRONGLY** recommended.
- Use of diesel fuel with sulfur content 0.10% (1000 ppm) to 0.50% (5000 ppm) may result in **REDUCED** oil and filter change intervals.
- **BEFORE** using diesel fuel with sulfur content greater than 0.50% (5000 ppm), contact your John Deere dealer.
- **DO NOT** use diesel fuel with sulfur content greater than 1.0%.

IMPORTANT: Do not mix used diesel engine oil or any other type of lubricating oil with diesel fuel.

IMPORTANT: Improper fuel additive usage may cause damage on fuel injection equipment of diesel engines.

DX,FUEL1 -19-17NOV05-1/1

Lubricity of Diesel Fuel

Most diesel fuels manufactured in the United States, Canada, and the European Union have adequate lubricity to ensure proper operation and durability of fuel injection system components. However, diesel fuels manufactured in some areas of the world may lack the necessary lubricity.

IMPORTANT: Make sure the diesel fuel used in your machine demonstrates good lubricity characteristics.

Fuel lubricity should pass a minimum load level of 3100 grams as measured by ASTM D6078 or a maximum scar diameter of 0.45 mm as measured by ASTM D6079 or ISO 12156-1.

If fuel of low or unknown lubricity is used, add John Deere PREMIUM DIESEL FUEL CONDITIONER (or equivalent) at the specified concentration.

DX,FUEL5 -19-27OCT05-1/1

Handling and Storing Diesel Fuel



CAUTION: Handle fuel carefully. Do not fill the fuel tank when engine is running.

DO NOT smoke while you fill the fuel tank or service the fuel system.

Fill the fuel tank at the end of each day's operation to prevent water condensation and freezing during cold weather.

Keep all storage tanks as full as practicable to minimize condensation.

Ensure that all fuel tank caps and covers are installed properly to prevent moisture from entering.

Monitor water content of the fuel regularly.

When using bio-diesel fuel, the fuel filter may require more frequent replacement due to premature plugging.

Check engine oil level daily prior to starting engine. A rising oil level may indicate fuel dilution of the engine oil.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace it with an original vented cap.

When fuel is stored for an extended period or if there is a slow turnover of fuel, add a fuel conditioner to stabilize the fuel and prevent water condensation. Contact your fuel supplier for recommendations.

DX,FUEL4 -19-19DEC03-1/1

Testing Diesel Fuel

DIESELSCAN™ is a John Deere fuel analysis program that can be used to monitor the quality of your fuel. The DIESELSCAN analysis verifies fuel type, cleanliness, water content, suitability for cold weather operation, and whether the fuel meets specifications.

Check with your John Deere dealer for availability of DIESELSCAN kits.

DIESELSCAN is a trademark of Deere & Company

DX,FUEL6 -19-14NOV05-1/1

Bio-Diesel Fuel

Consult your local fuel distributor for properties of the bio-diesel fuel available in your area.

Bio-diesel fuels may be used ONLY if the bio-diesel fuel properties meet the latest edition of ASTM D6751, EN 14214, or equivalent specification.

It is recommended to purchase bio-diesel fuel blended with B100 from a BQ-9000 Accredited Producer or a BQ-9000 Certified Marketer as recommended by the National Bio-diesel Board.

The maximum allowable bio-diesel concentration is a 5% blend (also known as B5) in petroleum diesel fuel. It has been found that bio-diesel fuels may improve lubricity in concentrations up to this 5% blend.

When using a blend of bio-diesel fuel, the engine oil level must be checked daily when the air temperature is -10°C (14°F) or lower. If oil becomes diluted with fuel, shorten oil change intervals accordingly.

IMPORTANT: Raw pressed vegetable oils are NOT acceptable for use as fuel in any concentration in John Deere engines.

These oils do not burn completely, and will cause engine failure by

leaving deposits on injectors and in the combustion chamber.

A major environmental benefit of bio-diesel fuel is its ability to biodegrade. This makes proper storage and handling of bio-diesel fuel especially important. Areas of concern include:

- Quality of new fuel
- Water content of the fuel
- Problems due to aging of the fuel

Potential problems resulting from deficiencies in the above areas when using bio-diesel fuel in concentrations above 5% may lead to the following symptoms:

- Power loss and deterioration of performance
- Fuel leakage
- Corrosion of fuel injection equipment
- Coked and/or blocked injector nozzles, resulting in engine misfire
- Filter plugging
- Lacquering and/or seizure of internal components
- Sludge and sediments
- Reduced service life of engine components

Consult your fuel supplier for additives to improve storage and performance of bio-diesel fuels.

DX,FUEL7 -19-14NOV05-1/1

Aviation (Jet) Fuels

Aviation (jet) fuels may be used with the following restrictions.

| Type | Comments |
|---------|---|
| Jet A | Lower viscosity and density than base No. 2-D diesel fuel. Power loss up to 10% can be expected. |
| Jet A-1 | Lower viscosity and density than base No. 2-D diesel fuel. Power loss up to 10% can be expected. |
| Jet B | Not Recommended. Lower density and extremely low viscosity compared to base No. 2-D diesel fuel. Power loss up to 14% can be expected. |
| JP-4 | Not Recommended. Lower density and extremely low viscosity compared to base No. 2-D diesel fuel. Power loss up to 12% can be expected. |
| JP-5 | Lower viscosity and density than base No. 2-D diesel fuel. Power loss up to 9% can be expected. |
| JP-7 | Lower viscosity and density than base No. 2-D diesel fuel. Power loss up to 10% can be expected. |
| JP-8 | Lower viscosity and density than base No. 2-D diesel fuel. Power loss up to 10% can be expected. |

OURGP12,000003F -19-07JUL04-1/1

Burner Fuels

Burner fuels, like kerosene, may be used with the following restrictions.

| Type | Comments |
|------|---|
| No.2 | Higher density and specific gravity than base No. 2-D diesel fuel. Power increase up to 3% can be expected. |
| No.1 | Lower viscosity than base No. 2-D diesel fuel. Power loss up to 2% can be expected. |

OURGP12,0000040 -19-07JUL04-1/1

Minimizing the Effect of Cold Weather on Diesel Engines

John Deere diesel engines are designed to operate effectively in cold weather.

However, for effective starting and cold weather operation, a little extra care is necessary. The information below outlines steps that can minimize the effect that cold weather may have on starting and operation of your engine. See your John Deere dealer for additional information and local availability of cold weather aids

Use Winter Grade Fuel

When temperatures fall below 5°C (40°F), winter grade fuel (Grade No. 1-D fuel in North America) is best suited for cold weather operation. Winter grade fuel has a lower cloud point and a lower pour point.

Cloud point is the temperature at which wax will begin to form in the fuel and this wax causes fuel filters to plug. **Pour point** is the temperature at which fuel begins to thicken and becomes more resistant to flow through fuel pumps and lines.

NOTE: On an average, winter grade fuel has a lower BTU (heat content) rating. Using winter grade fuel may reduce power and fuel efficiency, but should not cause any other engine performance effects. Check the grade of fuel being used before troubleshooting for low power complaints in cold weather operation.

Air Intake Heater

An air intake heater is an available option to aid cold weather starting.

 **CAUTION: Do not use any starting fluid with an air intake heater.**

Starting Fluid

A starting fluid port on the intake is available to aid cold weather starting.



CAUTION: Do not use any starting fluid with an engine equipped with glow plugs

Coolant Heater

An engine block heater (coolant heater) is an available option to aid cold weather starting.

Seasonal Viscosity Oil and Proper Coolant Concentration

Use seasonal grade viscosity engine oil based on the expected air temperature range between oil changes and proper concentration of low silicate antifreeze as recommended. (See DIESEL ENGINE OIL and ENGINE COOLANT requirements this section.)

Diesel Fuel Flow Additive

Use John Deere Premium Diesel Fuel Conditioner (Winter) or equivalent to treat fuel during the cold weather season. This winter formulation is a combination diesel fuel conditioner and anti-gel additive.

IMPORTANT: Treat fuel when outside temperature drops below 0°C (32°F). For best results, use with untreated fuel. Follow all recommended instructions on label.

Winterfronts

Use of fabric, cardboard, or solid winterfronts is not recommended with any John Deere engine. Their use can result in excessive engine coolant, oil, and charge air temperatures. This can lead to reduced engine life, loss of power and poor fuel economy. Winterfronts may also put abnormal stress on fan and fan drive components potentially causing premature failures.

If winterfronts are used, they should never totally close off the grill frontal area. Approximately 25% area in the center of the grill should remain open at all times. At no time should the air blockage device be applied directly to the radiator core.

Radiator Shutters

If equipped with a thermostatically controlled radiator shutter system, this system should be regulated in such a way that the shutters are completely open by

the time the coolant reaches 93°C (200°F) to prevent excessive intake manifold temperatures. Manually controlled systems are not recommended.

If air-to-air aftercooling is used, the shutters must be completely open by the time the intake manifold air temperature reaches the maximum allowable temperature out of the charge air cooler.

For more information, see your John Deere dealer.

DX,FUEL10 -19-16DEC05-2/2

Diesel Engine Break-In Oil

New engines are filled at the factory with John Deere ENGINE BREAK-IN OIL. During the break-in period, add John Deere ENGINE BREAK-IN OIL as needed to maintain the specified oil level.

Change the oil and filter after the first 100 hours of operation of a new or rebuilt engine.

After engine overhaul, fill the engine with John Deere ENGINE BREAK-IN OIL.

If John Deere ENGINE BREAK-IN OIL is not available, use a diesel engine oil meeting one of the following during the first 100 hours of operation:

- API Service Classification CE
- API Service Classification CD
- API Service Classification CC
- ACEA Oil Sequence E2

- ACEA Oil Sequence E1

After the break-in period, use John Deere PLUS-50™ or other diesel engine oil as recommended in this manual.

IMPORTANT: Do not use PLUS-50 oil or engine oils meeting any of the following during the first 100 hours of operation of a new or rebuilt engine:

| | |
|---------------|---------|
| API CI-4 PLUS | API CF |
| API CI-4 | ACEA E7 |
| API CH-4 | ACEA E6 |
| API CG-4 | ACEA E5 |
| API CF-4 | ACEA E4 |
| API CF-2 | ACEA E3 |

These oils will not allow the engine to break-in properly.

PLUS-50 is a trademark of Deere & Company.

DX,ENOIL4 -19-19DEC05-1/1

Diesel Engine Oil

Use preferably **multi-viscosity** oils based on the expected air temperature range during the period between oil changes.

John Deere PLUS-50™ is the preferred diesel engine oil.

Oil meeting one of the following specifications are also recommended:


- ACEA Oil Sequence E7
- ACEA Oil Sequence E6
- ACEA Oil Sequence E5
- ACEA Oil Sequence E4

Extended service intervals may apply when John Deere PLUS-50™, ACEA E7, ACEA E6, ACEA E5, or ACEA E4 engine oils are used. Consult your John Deere dealer for more information.

Other oils may be used if they meet one or more of the following:

- John Deere TORQ-GARD SUPREME™
- API Service Category CI-4 PLUS
- API Service Category CI-4
- API Service Category CH-4
- ACEA Oil Sequence E3

When using the specified John Deere oil filter with the oil shown in the following table for each engine, the corresponding service interval applies. Intervals shown in the table are the **maximum** (not-to-exceed) service intervals.



Diesel Engine Oil

TS1668A -UN-14DEC01

PLUS-50 is a trademark of Deere & Company.
TORQ-GARD SUPREME is a trademark of Deere & Company

Continued on next page

OUID006,0000002 -19-31MAY06-1/2

Recommended Engine Oil and Filter Service Intervals

| Engine Type | PLUS-50™ and ACEA-E7/E6/E5/E4 Oils Only | TORQ-GARD SUPREME or API CI-4 Plus, CI-4/CH-4, ACEA-E3 Oils |
|--|---|---|
| Emission Non-Certified and Tier I Emission Certified | 375 Hours | 250 Hours |
| Tier II Emission Certified (3029TF270) | 500 Hours | 250 Hours |

Diesel fuel quality and sulfur content must comply with all existing emissions regulations for the area in which the engine operates.

If diesel fuel with sulfur content greater than 0.05% (500 ppm) is used, reduce the oil and filter service interval by 100 hours.

If diesel fuel with sulfur content greater than 0.5% (5000 ppm) is used, reduce the service interval by 50%.

Diesel fuel with sulfur content greater than 1.0% (10,000 ppm) is not recommended.

PLUS-50 is a trademark of Deere & Company.

OUOD006,0000002 -19-31MAY06-2/2

Mixing of Lubricants

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Consult your John Deere dealer to obtain specific information and recommendations.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.


DX.LUBMIX -19-18MAR96-1/1

OILSCAN™ and COOLSCAN™


OILSCAN™ and COOLSCAN™ are John Deere sampling programs to help you monitor machine performance and identify potential problems before they cause serious damage.

Oil and coolant samples should be taken from each system prior to its recommended change interval.

Check with your John Deere dealer for the availability of OILSCAN™ and COOLSCAN™ kits.



T6828AB -JUN-15JUN89



T6829AB -JUN-18OCT88

*OILSCAN is a registered trademark of Deere & Company.
COOLSCAN is a trademark of Deere & Company.*

DX,OILSCAN -19-02DEC02-1/1

Alternative and Synthetic Lubricants

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic oils.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-15JUN00-1/1

Lubricant Storage

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Whenever possible, store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-18MAR96-1/1

Grease

Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

John Deere SD POLYUREA GREASE is preferred.


The following greases are also recommended

- John Deere HD LITHIUM COMPLEX GREASE
- John Deere HD WATER RESISTANT GREASE
- John Deere GREASE-GARD™

Other greases may be used if they meet the following:

NLGI Performance Classification GC-LB

IMPORTANT: Some types of grease thickeners are not compatible with others. Consult your grease supplier before mixing different types of grease



GREASE-GARD is a trademark of Deere & Company

DX,GRE1 -19-07NOV03-1/1

Diesel Engine Coolant

The engine cooling system is filled to provide year-round protection against corrosion and cylinder liner pitting, and winter freeze protection to -37°C (-34°F). If protection at lower temperatures is required, consult your John Deere dealer for recommendations.

John Deere COOL-GARD™ Prediluted Coolant is preferred for service.

John Deere COOL-GARD Prediluted Coolant is available in a concentration of either 50% ethylene glycol or 55% propylene glycol.

Additional recommended coolants

The following engine coolant is also recommended:

- John Deere COOL-GARD Coolant Concentrate in a 40% to 60% mixture of concentrate with quality water.

John Deere COOL-GARD coolants do not require use of supplemental coolant additives, except for periodic replenishment of additives during the drain interval.

Other fully formulated coolants

Other fully formulated low silicate ethylene or propylene glycol base coolants for heavy-duty engines may be used if they meet one of the following specifications:

- ASTM D6210 prediluted (50%) coolant
- ASTM D6210 coolant concentrate in a 40% to 60% mixture of concentrate with quality water

Coolants meeting ASTM D6210 do not require use of supplemental coolant additives, except for periodic replenishment of additives during the drain interval.

Coolants requiring supplemental coolant additives

Other low silicate ethylene glycol base coolants for heavy-duty engines may also be used if they meet one of the following specifications:

- ASTM D4985 ethylene glycol base prediluted (50%) coolant
- ASTM D4985 ethylene glycol base coolant concentrate in a 40% to 60% mixture of concentrate with quality water

Coolants meeting ASTM D4985 require an initial charge of supplemental coolant additives, formulated for protection of heavy duty diesel engines against corrosion and cylinder liner erosion and pitting. They also require periodic replenishment of additives during the drain interval.

Other coolants

It is possible that neither John Deere COOL-GARD nor coolants meeting one of the coolant standards listed above is available in the geographical area where service is performed. If these coolants are unavailable, use a coolant concentrate or prediluted coolant with a quality additive package that provides cylinder liner cavitation protection and protects the cooling system metals (cast iron, aluminum alloys, and copper alloys such as brass) from corrosion.

The additive package must be part of one of the following coolant mixtures:

- ethylene glycol or propylene glycol base prediluted (40% to 60%) coolant
- ethylene glycol or propylene glycol base coolant concentrate in a 40% to 60% mixture of concentrate with quality water

Water quality

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol and propylene glycol base engine coolant concentrate.

IMPORTANT: Do not mix ethylene glycol and propylene glycol base coolants.

IMPORTANT: Do not use cooling system sealing additives or antifreeze that contains sealing additives.

DX,COOL3 -19-27OCT05-2/2

Additional Information About Diesel Engine Coolants and Supplemental Coolant Additives

Engine coolants are a combination of three chemical components: ethylene glycol or propylene glycol antifreeze, inhibiting coolant additives, and quality water.

Coolant specifications

Some products, including John Deere COOL-GARD™ Prediluted Coolant, are fully formulated coolants that contain all three components in their correct concentrations. Do not add an initial charge of supplemental coolant additives to these fully formulated products.

Coolants meeting ASTM D6210 do not require an initial charge of supplemental coolant additives.

Some coolant concentrates, including John Deere COOL-GARD Coolant Concentrate, contain both glycol antifreeze and inhibiting coolant additives. Mix these products with quality water, but do not add an initial charge of supplemental coolant additives.

Coolants meeting ASTM D4985 require an initial charge of supplemental coolant additives.

Replenish coolant additives

The concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere COOL-GARD or another fully formulated coolant is used. Follow the recommendations in this manual for the use of supplemental coolant additives.

Why use supplemental coolant additives?

Operating without proper coolant additives will result in increased corrosion, cylinder liner erosion and pitting, and other damage to the engine and cooling system. A

simple mixture of ethylene glycol or propylene glycol and water will not give adequate protection.

Use of supplemental coolant additives reduces corrosion, erosion, and pitting. These chemicals reduce the number of vapor bubbles in the coolant and help form a protective film on cylinder liner surfaces. This film acts as a barrier against the harmful effects of collapsing vapor bubbles.

Avoid automotive-type coolants

Never use automotive-type coolants (such as those meeting ASTM D3306). These coolants do not contain the correct additives to protect heavy-duty diesel engines. They often contain a high concentration of silicates and may damage the engine or cooling system.

Water quality

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol and propylene glycol base engine coolant concentrate. All water used in the cooling system should meet the following minimum specifications for quality:

| | |
|------------------------|------------|
| Chlorides | <40 mg/L |
| Sulfates | <100 mg/L |
| Total dissolved solids | <340 mg/L |
| Total hardness | <170 mg/L |
| pH | 5.5 to 9.0 |

Freeze protection

The relative concentrations of glycol and water in the engine coolant determine its freeze protection limit.

| Ethylene Glycol | Freeze Protection Limit |
|------------------|-------------------------|
| 40% | -24°C (-12°F) |
| 50% | -37°C (-34°F) |
| 60% | -52°C (-62°F) |
| Propylene Glycol | Freeze Protection Limit |
| 40% | -21°C (-6°F) |
| 50% | -33°C (-27°F) |
| 60% | -49°C (-56°F) |

DO NOT use a coolant-water mixture greater than 60% ethylene glycol or 60% propylene glycol.

DX.COOL7 -19-19DEC03-2/2

Testing Diesel Engine Coolant

Testing Diesel Engine Coolant

Maintaining adequate concentrations of glycol and inhibiting additives in the coolant is critical to protect the engine and cooling system against freezing, corrosion, and cylinder liner erosion and pitting.

Test the coolant solution at intervals of 12 months or less and whenever excessive coolant is lost through leaks or overheating.

Coolant test strips

Coolant test strips are available from your John Deere dealer. These test strips provide a simple, effective

method to check the freeze point and additive levels of your engine coolant.

Compare the results to the supplemental coolant additive (SCA) chart to determine the amount of inhibiting additives in your coolant and whether more John Deere COOLANT CONDITIONER should be added.

COOLSCAN™ and COOLSCAN PLUS™

For a more thorough evaluation of your coolant, perform a COOLSCAN or COOLSCAN PLUS analysis, where available. See your John Deere dealer for information.

COOLSCAN is a trademark of Deere & Company
COOLSCAN PLUS is a trademark of Deere & Company

DX.COOL9 -19-19DEC03-1/1

Supplemental Coolant Additives

The concentration of coolant additives is gradually depleted during engine operation. For all recommended coolants, replenish additives between drain intervals by adding a supplemental coolant additive every 12 months or as determined necessary by coolant testing.

John Deere COOLANT CONDITIONER is recommended as a supplemental coolant additive in John Deere engines.

IMPORTANT: Do not add a supplemental coolant additive when the cooling system is drained and refilled with John DeereCOOL-GARD™.

If other coolants are used, consult the coolant supplier and follow the manufacturer's recommendation for use of supplemental coolant additives.

The use of non-recommended supplemental coolant additives may result in additive drop-out and gelation of the coolant.

Add the manufacturer's recommended concentration of supplemental coolant additive. DO NOT add more than the recommended amount.

COOL-GARD is a trademark of Deere & Company

DX,COOL4 -19-07NOV03-1/1

Operating in Warm Temperature Climates

John Deere engines are designed to operate using glycol base engine coolants.

Always use a recommended glycol base engine coolant, even when operating in geographical areas where freeze protection is not required.

IMPORTANT: Water may be used as coolant *in emergency situations only.*

Foaming, hot surface aluminum and iron corrosion, scaling, and cavitation will occur when water is used as the coolant, even when coolant conditioners are added.

Drain cooling system and refill with recommended glycol base engine coolant as soon as possible.

DX,COOL6 -19-18MAR96-1/1


Disposing of Coolant

Improperly disposing of engine coolant can threaten the environment and ecology.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere engine distributor or servicing dealer.



Recycle Waste

T51133 -UN-26NOV90

RG, RG34710, 7543 -19-24JAN03-1/1

Engine Operating Guidelines

Instrument (Gauge) Panels

IMPORTANT: Any time an electric gauge or meter does not register correctly, replace it with a new one. Do not attempt to repair it.

All controls and gauges covered in this manual are optional equipment for John Deere OEM Engines. They may be provided by the equipment manufacturer instead of John Deere. The following information applies only to those controls and gauges provided by John Deere.

Continued on next page

OUOD006,0000001 -19-26MAY06-1/8

Earlier Instrument (Gauge) Panel (North America)

Following is a brief description of the components on the John Deere instrument (gauge) panel:

A—Oil Pressure Gauge - Indicates engine oil pressure.

B—Coolant Temperature Gauge - Indicates the engine coolant temperature.

C—Key Switch - The four position key switch controls the electrical system.

D—Tachometer (optional) - Indicates engine speed in revolutions per minute (rpm).


E—Reset (Safety) Switch - Overrides safety shutdown switch when depressed and held in during engine start-up. Hold button in until engine oil pressure is at a safe operating level.

F—Fuse Holder - Contains 14 amp fuse.

G—Ammeter - Indicates charging current within electrical system.

H—Hour Meter (optional) - Indicates the operating hours of the engine while key switch is in the “ON” position. The hour meter should be used as a guide for scheduling periodic service.

I—Hand Throttle (optional) - Controls engine speed.



RG11527 -UN-01DEC00

North American Instrument Panel (Earlier Engines)

- A—Oil Pressure Gauge
- B—Coolant Temperature Gauge
- C—Key Switch
- D—Tachometer
- E—Reset (Safety) Switch
- F—Fuse Holder
- G—Ammeter
- H—Hour Meter
- I—Hand Throttle

Continued on next page

OUOD006,0000001 -19-26MAY06-2/8

Later Instrument (Gauge) Panel (North America)

IMPORTANT: Any time an electric gauge or meter does not register correctly, replace it with a new one. Do not attempt to repair it.

Following is a brief description of the components on instrument (gauge) panel:

A—Tachometer with Hourmeter (Optional) - The tachometer with hourmeter indicates engine speed in revolutions per minute (rpm) and shows the operating hours of the engine while key switch is in the "ON" position. The hour meter should be used as a guide for scheduling periodic service.

B—Oil Pressure Gauge - The oil pressure gauge indicates engine oil pressure. If the engine oil pressure falls below a safe operating pressure, the engine will shut down.

C—Voltmeter Gauge - The voltmeter indicates system battery voltage.


D—Coolant Temperature Gauge - The coolant temperature gauge indicates the engine coolant temperature. If coolant temperature rises above the preset, safe operating temperature, the engine will shut down.

E—Pre-Heat Button - Press button to activate the preheater for cold weather starting.

F—Reset (Safety) Switch- Reset button will pop out and shut down the engine if the coolant temperature is too high or oil pressure is too low. Press in and hold while starting engine until oil pressure is at a safe operating level.

G—Fuse Holder - Contains 14 amp fuse.

H—Key Switch - The key switch controls the electrical system. Positions of key switch are marked as follows: OFF, ON, and START.



Instrument Panel and Gauges (Later Engines)

- A—Tachometer with Hourmeter (Optional)
- B—Oil Pressure Gauge
- C—Voltmeter Gauge
- D—Coolant Temperature Gauge
- E—Preheat Button
- F—Reset (Safety) Switch
- G—Fuse Holder
- H—Key Switch
- I—Throttle (Optional)
- J—Hourmeter (Optional)

RG13360 -JUN-06FEB04

I—Throttle (Optional) - The throttle control is used to control engine speed.

J—Hourmeter (Optional) - The hourmeter indicates the operating hours of the engine while key switch is in the "ON" position. The hour meter should be used as a guide for scheduling periodic service.

Continued on next page

OUOD006,0000001 -19-26MAY06-4/8

AEZ Instrument (Gauge) Panel (Except North America)

A—Oil Pressure Gauge - The oil pressure gauge indicates engine oil pressure.

B—Coolant Temperature Gauge - The coolant temperature gauge indicates the engine coolant temperature.

C—Engine Control Light - The engine control light indicates that the engine protection is activated.


D—Oil Pressure Light - The oil pressure light illuminates when the key switch is turned to the CONTROL position. The light will remain on until the engine is started and the specified oil pressure is reached. If oil pressure is lost during engine operation, the light will illuminate and protection circuitry will stop the engine. The oil pressure light will remain on, indicating that the engine was stopped due to a low oil pressure condition.

E—Alternator Light - The alternator light illuminates when the key is turned to the CONTROL position. The light will remain on until the engine is started. After the engine is running, if the alternator stops charging, the light will illuminate and protection circuitry will stop the engine. The alternator light will remain on indicating the engine was stopped due to the alternator not charging.

F—Coolant Temperature Light - The coolant temperature light illuminates only if the engine has overheated. After the engine is running, if the engine overheats, the light will illuminate and protection circuitry will stop the engine. The coolant temperature light will remain on indicating the engine was stopped due to the engine overheating.

G—Fuel Level Light - The fuel level light illuminates only if the engine has stopped due to fuel tank being empty. After the engine is running, if the engine runs out of fuel, the light will illuminate. The fuel level light will remain on indicating the engine was stopped due to the fuel tank being empty.

H—Key Switch - The key switch controls the electrical system.



AEZ Instrument Panel

- A—Oil Pressure Gauge
- B—Coolant Temperature Gauge
- C—Engine Control Light
- D—Oil Pressure Light
- E—Alternator Light
- F—Coolant Temperature Light
- G—Fuel Level Light
- H—Key Switch
- I—Hour Meter
- J—Tachometer

RG11590 -JUN-08DEC00

I—Hour Meter - Indicates the operating hours of the engine while key switch is in the “ON” position. The hour meter should be used as a guide for scheduling periodic service.

J—Tachometer - Indicates engine speed in revolutions per minute (rpm).

Continued on next page

OUOD006,0000001 -19-26MAY06-6/8

VDO Instrument (Gauge) Panel (Except North America)

A—Oil Pressure Gauge - The oil pressure gauge indicates engine oil pressure.

B—Coolant Temperature Gauge - The coolant temperature gauge indicates coolant temperature.

C—Tachometer - The tachometer indicates engine speed in hundreds of revolutions per minute (rpm).


The engine control system consists of the following:

D—Engine Control Light - The engine control light illuminates after the engine has started and oil pressure is up to specification. The light indicates that the engine protection circuitry is activated.

E—Preheater Light - The preheater light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. When the key switch is held in position II, the engine preheater is energized and the preheater light illuminates.

F—Fuel Level Light - The fuel level light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the engine runs out of fuel, the light will illuminate. The fuel level light will remain on indicating the engine was stopped due to the fuel tank being empty.

G—Battery Light - The battery light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the alternator stops charging, the light will illuminate and protection circuitry will stop the engine. The battery light will remain on indicating the engine was stopped due to the alternator not charging.



- A—Oil Pressure Gauge
- B—Coolant Temperature Gauge
- C—Tachometer
- D—Engine Control Light
- E—Preheater Light
- F—Fuel Level Light
- G—Battery Light
- H—Oil Pressure Light
- I—Coolant Temperature Light
- J—Key/Start Switch
- K—Hour Meter

RG10606B -JUN-20OCT199

Continued on next page

OUOD006,0000001 -19-26MAY06-7/8

H—Oil Pressure Light - The oil pressure light illuminates when the key switch is turned to the bulb test position (position I). The light will remain on until the engine is started and the specified oil pressure is reached. If oil pressure is lost during engine operation, the light will illuminate and protection circuitry will stop the engine. The oil pressure light will remain on, indicating that the engine was stopped due to a low oil pressure condition.

I—Coolant Temperature Light - The coolant temperature light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the engine overheats, the light will illuminate and protection circuitry will stop the engine. The coolant temperature light will remain on indicating the engine was stopped due to the engine overheating.

Other components on the instrument panel:

J—Key/Start Switch - The four-position key start switch controls the electrical system.

K—Hour Meter - The hour meter is an integral part of the tachometer. It shows the accumulated hours of engine service. The hour meter operates when the engine is running and accumulated hours are displayed in hours and tenths of hours.

OUOD006,0000001 -19-26MAY06-8/8

Auxiliary Gear Drive Limitations

IMPORTANT: When attaching an air compressor, hydraulic pump, or other accessory to be driven by the auxiliary gear drive (engine timing gear train at front of engine), power requirements of the accessory must be limited to values listed below:



CD30354 -UN-03FEB93

Power Levels For Right-Hand Auxiliary Gear Drive:

- 16 kW (22 hp) Continuous Operation¹
- 28 kW (37.5 hp) Intermittent Operation¹

Auxiliary Gear Drive

¹At 2400 engine rpm.

RG, RG34710, 5047 -19-30JAN98-1/1

Generator Set (Standby) Applications

To assure that your engine will deliver efficient standby operation when needed, start engine and run at rated speed (with 50%—70% load) for 30 minutes every 2 weeks. DO NOT allow engine to run extended period of time with no load.

RG, RG34710, 5048 -19-30JAN98-1/1

Starting The Engine

The following instructions apply to the optional controls and instruments available through the John Deere Parts Distribution Network. The controls and instruments for your engine may be different from those shown here; always follow manufacturer's instructions.


Continued on next page

RG, RG34710, 5049 -19-30JAN98-1/1

CAUTION: Before starting engine in a confined building, install proper outlet exhaust ventilation equipment. Always use safety approved fuel storage and piping.

NOTE: If temperature is below 0 °C (32 °F), it may be necessary to use cold weather starting aids (See COLD WEATHER OPERATION, later in this section).

1. Perform all prestarting checks outlined in Lubrication & Maintenance/Daily Section later in this manual.
2. Open the fuel supply shut-off valve, if equipped.




Avoid Toxic Fumes

TSS220 -JUN-23AUG88

RG, RG34710, 5049 -19-30JAN98-2/4

3. If equipped with PTO clutch, pull lever (arrow) rearward (away from engine) to disengage PTO clutch.



PTO Clutch Lever

RG5602 -JUN-16JUN00

Continued on next page

RG, RG34710, 5049 -19-30JAN98-3/4

4. Pull hand throttle (A) 1/3 of the way out. Turn the handle in either direction to lock it in place.
5. If equipped, depress and hold reset button (B) while starting.

IMPORTANT: Do not operate the starter for more than 30 seconds at a time. To do so may overheat the starter. If the engine does not start the first time, wait at least 2 minutes before trying again. If engine does not start after four attempts, see Troubleshooting Section.

6. Turn the key switch (C) clockwise to crank the engine. When the engine starts, release the key so that it returns to the "ON" position.


IMPORTANT: If the key switch is released before the engine starts, wait until the starter and the engine stop turning before trying again. This will prevent possible damage to the starter and/or flywheel.

7. After the engine starts, continue to hold the reset button in until the oil pressure gauge (D) reads at least 105 kPa (1.05 bar) (15 psi). The safety controls will not allow the engine to run at a lower oil pressure unless the reset button is held in.

IMPORTANT: Should the engine die while operating under load, immediately disengage PTO clutch and restart the engine. Overheating of turbocharger parts may occur when oil flow is stopped.

8. Check all gauges for normal engine operation. If operation is not normal, stop the engine and determine the cause.

- A—Hand Throttle
- B—Reset Button
- C—Key Switch
- D—Oil Pressure Gauge




RG11532 -UN-01DEC00

North American Instrument Panel



RG11592 -UN-17JAN01

AEZ Instrument Panel (Except North America)



RG11588

VDO Instrument Panel (Except North America)


RG11588 -UN-08DEC00

RG, RG34710, 5049 -19-30JAN98-4/4

Break-In Service



Check Engine Oil Level



A—Full Mark

B—Crosshatch

The engine is ready for normal operation. However, extra care during the first 100 hours of operation will result in more satisfactory long-term engine performance and life. DO NOT exceed 100 hours of operation with break-in oil.

1. This engine is factory-filled with a special break-in oil. Operate the engine at heavy loads with minimal idling during the break-in period.

IMPORTANT: Do not add makeup oil until the level is **BELOW** the ADD mark or lower arrow on dipstick. If make-up oil is required during the break-in period, an additional 100 hour break-in period is required. John Deere Engine Break-In Oil (TY22041) should be used to make up any oil consumed during the break-in period.

DO NOT fill above the top of the mark (A) or crosshatch pattern (B), whichever is present. Oil levels anywhere within arrows or

crosshatch are considered in the acceptable operating range.

2. Check engine oil level more frequently. If oil must be added, John Deere Engine Break-In Oil is preferred. See ENGINE BREAK-IN OIL, in Fuels, Lubricants, and Coolant Section.
3. Check oil pressure and coolant temperature while engine is operating. See specification.

Specification

| | |
|---|---|
| Engine ¹ —Oil Pressure at Full Load Rated Speed..... | 345 ± 103 kPa (3.45 ± 1.03 bar) (50 ± 15 psi) |
| Minimum Oil Pressure at Rated Speed..... | 275 (2.75 bar) (40 psi) |
| Minimum Oil Pressure at 850 rpm..... | 105 kPa (1.05 bar) (15 psi) |
| Coolant Temperature Range | 82°—94°C (180°—202°F) |

4. During the first 20 hours, avoid prolonged periods of engine idling or sustained maximum load operation. Vary the engine speed throughout this period. If engine will idle longer than 5 minutes, stop engine.

¹At normal operating temperature of 115 °C (240 °F) sump.




North American Instrument Panel

RG11531 -JUN-01DEC00



AEZ Instrument Panel (Except North America)

RG11591 -JUN-08DEC00



RG11587

VDO Instrument Panel (Except North America)

RG11587 -JUN-07DEC00

A—Coolant Temperature Gauge


5. Watch coolant temperature gauge (A) closely. If coolant temperature rises above 112°C (234°F), reduce load on engine. Unless temperature drops quickly, stop the engine and determine the cause before resuming operation.

NOTE: When the coolant temperature gauge reads approximately 115°C (239°F), the engine will shutdown automatically, if equipped with safety controls.

6. The tension on newly installed belts should be checked daily for the first few days of operation because of the initial stretching. Also, check belts for proper seating in pulley grooves.


RG, RG34710, 5046 -19-11FEB03-2/2

After Break-In Service



RG11529 -UN-01DEC00

Engine Mounted Oil Filter



RG11530 -UN-01DEC00

Engine Mounted Oil Filter


NOTE: If the engine has significant operating time at idle, constant speeds, and/or light load usage, or make-up oil is required in the first 100 hour period, a longer break-in period may be required. In these situations, an additional 100 hour break-in period is recommended using a new change of John Deere Engine Break-In Oil and new John Deere oil filter.

After break-in service, change engine oil and oil filter (A) according to maintenance interval indicated below.

All except 3029TF270 Engines: See CHANGING ENGINE OIL AND REPLACING OIL FILTER in Lubrication and Maintenance/250 Hour Section.

3029TF270 Engines: (See CHANGING ENGINE OIL AND REPLACING OIL FILTER in Lubrication and Maintenance/500 Hour Section.)

Fill crankcase with seasonal viscosity grade oil. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant Section.)



RG11549 -UN-06DEC00

3029 Engines with Remote Oil Filter

A—Oil Filter

Normal Engine Operation

Observe engine coolant temperature and engine oil pressure. Temperatures and pressures will vary between engines and with changing operating conditions, temperatures, and loads.

Normal engine coolant operating temperature range is 82°–94°C (180°–202°F). If coolant temperature rises above 112°C (234°F), reduce load on engine. Unless temperature drops quickly, stop engine and determine cause before resuming operation.

Operate the engine under a lighter load and at slower than normal speed for first 15 minutes after start-up. DO NOT run engine at slow idle.

IMPORTANT: Should the engine die while operating under load, immediately

remove load and restart the engine. Overheating of the turbocharger parts may occur when oil flow is stopped.

Stop engine immediately if there are any signs of part failure. Symptoms that may be early signs of engine problems are:

- Sudden drop in oil pressure
- Abnormal coolant temperatures
- Unusual noise or vibration
- Sudden loss of power
- Excessive black exhaust
- Excessive fuel consumption
- Excessive oil consumption
- Fluid leaks

RG, RG34710, 5045 -19-30JAN98-1/1

Cold Weather Operation

CAUTION: Ether injector starting fluid is highly flammable. **DO NOT** use starting fluid on engines equipped with air intake heaters.

DO NOT use starting fluid near fire, sparks, or flames. **DO NOT** incinerate or puncture a starting fluid container.

Engines may be equipped with intake air heaters, coolant heaters, or ether injectors as a cold weather starting aid.

Starting aids are required below 0°C (32°F). They will enhance starting performance above these temperatures and may be needed to start applications that have high parasitic loads during cranking and/or start acceleration to idle.

Using correct grade of oil (per engine and machine operator's manual) is critical to achieving adequate cold weather cranking speed.


Other cold weather starting aids are required at temperatures below -30°C (-22°F) or at altitudes above 1500 m (5000 ft).

1. Follow steps 1—4 as listed under "STARTING THE ENGINE", then proceed as follows according to the instrument (control) panel on your engine.
2. Switch on the air intake heater for 30 seconds or activate ether injector by following suppliers instructions.
3. Follow remaining steps 5—8 as listed under "STARTING THE ENGINE" earlier in this section.

Additional information on cold weather operation is available from your authorized servicing dealer.



Handle Starting Fluid with Care



Cold Weather Starting Guidelines

T51356 -UN-18MAR92

RG11521 -19-10JAN01

RG, RG34710, 5050 -19-11FEB03-1/1

Warming Engine

IMPORTANT: To assure proper lubrication, operate engine at or below 1200 rpm with no load for 1–2 minutes. Extend this period 2–4 minutes when operating at temperatures below freezing.

Engines used in generator set applications where the governor is locked at a specified speed may not have a slow idle function. Operate these engines at high idle for 1 to 2 minutes before applying the load. This procedure does not apply to standby generator sets where the engine is loaded immediately upon reaching rated speed.

1. Check oil pressure gauge (A) as soon as engine starts. If gauge needle does not rise above minimum oil pressure specification of 105 kPa (1.05 bar) (15.0 psi) within 5 seconds, stop the engine and determine the cause. Normal engine oil pressure is 345 ± 103 kPa ($3.45 \text{ bar} \pm 1.03 \text{ bar}$) (50 ± 15 psi) at rated full load speed (1800–2500 rpm) with oil at normal operating temperature of 105°C (221°F).
2. Watch coolant temperature gauge (B). Do not place engine under full load until it is properly warmed up. The normal engine coolant temperature range is 82°–94°C (180°–202°F).


NOTE: It is a good practice to operate the engine under a lighter load and at lower speeds than normal for the first few minutes after start-up.

- A**—Oil Pressure Gauge
B—Coolant Temperature Gauge




North American Instrument Panel

RG11533 –UN-01DEC00



AEZ Instrument Panel (Except North America)

RG11593 –UN-08DEC00



VDO Instrument Panel (Except North America)

RG10613 –UN-21OCT99

RG, RG34710, 5051 –19-30JAN98-1/1

Changing Engine Speed-Standard (Mechanical) Governor

NOTE: Throttle levers are usually supplied by OEM manufacturer. Consult supplier literature to familiarize yourself with throttle lever used on your engine.

To increase engine speed, turn throttle handle (A) to the horizontal position and pull out until desired engine speed is obtained. Turn the handle in either direction to lock throttle position. The handle is pushed inward to decrease engine speed.

A—Throttle Handle



RG11534 -JUN-01DEC00

Throttle Handle on North American Instrument Panel

RG, RG34710, 5052 -19-30JAN98-1/1

Idling Engine

Avoid excessive engine idling. Prolonged idling may cause the engine coolant temperature to fall below its normal range. This, in turn, causes crankcase oil dilution, due to incomplete fuel combustion, and permits formation of gummy deposits on valves, pistons, and piston rings. It also promotes rapid accumulation of engine sludge and unburned fuel in the exhaust system.

Once an engine is warmed to normal operating temperatures, engine should be idled at slow idle


speed. Slow idle speed for this engine is 850 rpm at factory. If an engine will be idling for more than 5 minutes, stop and restart later, or set engine speed at 1200 rpm.

NOTE: Generator set applications where the governor is locked at a specified speed may not have a slow idle function. These engines will idle at no load governed speed (high idle).

RG, RG34710, 5053 -19-11FEB03-1/1

Stopping The Engine

1. Pull PTO clutch lever (arrow) rearward (away from engine) to disengage clutch, if equipped.



PTO Clutch Lever

RG5602 -UN-16JUN00

Continued on next page

RG.RG34710,5054 -19-30JAN98-1/2

2. Move the throttle handle (A) to slow idle on standard (mechanical) governor engines.

IMPORTANT: Before stopping an engine that has been operating at working load, idle engine at least 2 minutes at 1000–1200 rpm to cool hot engine parts.

Engines in generator set applications, where the governor is locked at a specified speed and no slow idle function is available, run engine for at least 2 minutes at fast idle and no load.

3. Turn key switch to “OFF” position. Remove ignition key.

IMPORTANT: Make sure that exhaust stack cap (rain cap) is installed when engine is not running. This will prevent water and dirt from entering engine.



RG11534 -JUN-01DEC00

A—Throttle Handle

Throttle Handle on North American Instrument Panel



RG-10616 -JUN-16JUN00

Rain Cap

RG, RG34710, 5054 -19-30JAN98-2/2

Using A Booster Battery Or Charger

CAUTION: Gas given off by battery is explosive. Keep sparks and flames away from battery. Before connecting or disconnecting a battery charger, turn charger off. Make last connection and first disconnection at a point away from battery. Always connect **NEGATIVE (-)** cable last and disconnect this cable first.

IMPORTANT: Be sure polarity is correct before making connections. Reversed polarity will damage electrical system. Always connect positive to positive and negative to ground. Always use 12-volt booster battery for 12-volt electrical systems and 24-volt booster battery(ies) for 24-volt electrical systems.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

A 12-volt booster battery can be connected in parallel with battery(ies) on the unit to aid in cold weather starting. ALWAYS use heavy duty jumper cables.


1. Connect booster battery or batteries to produce the required system voltage for your engine application.

NOTE: To avoid sparks, **DO NOT** allow the free ends of jumper cables to touch the engine.


2. Connect one end of jumper cable to the **POSITIVE (+)** post of the booster battery.
3. Connect the other end of the jumper cable to the **POSITIVE (+)** post of battery connected to starter.
4. Connect one end of the other jumper cable to the **NEGATIVE (-)** post of the booster battery.
5. ALWAYS complete the hook-up by making the last connection of the **NEGATIVE (-)** cable to a good ground on the engine frame and away from the battery(ies).



Exploding Battery



12-Volt System



24-Volt System

A—12-Volt Machine Battery (ies)
 B—12-Volt Booster Battery (ies)
 C—Booster Cable
 D—Cable to Starting Motor

TSS204 -JUN-23AUG88

RG4678 -JUN-14DEC88

RG4698 -JUN-14DEC88

6. Start the engine. Disconnect jumper cables immediately after engine starts. Always disconnect NEGATIVE (-) cable first.

RG, RG34710, 4060 -19-01JAN96-2/2

Lubrication and Maintenance

Observe Service Intervals




North American Instrument Panel Hour Meter

RG11589 -JUN-08DEC00



AEZ Instrument Panel Hour Meter

RG11594 -JUN-08DEC00



VDO Instrument Panel Hour Meter

RG10618 -JUN-21OCT99

Using hour meter (A) as a guide, perform all services at the hourly intervals indicated on following pages. At each scheduled maintenance interval, perform all previous maintenance operations in addition to the ones specified. Keep a record of hourly intervals and services performed using charts provided in Lubrication and Maintenance Records Section.

IMPORTANT: Recommended service intervals are for normal operating conditions. Service **MORE OFTEN** if engine is operated under adverse conditions. Neglecting maintenance can result in failures or permanent damage to the engine.

A—Hour Meter

RG,RG34710,5056 -19-30JAN98-1/1

Use Correct Fuels, Lubricants, And Coolant

IMPORTANT: Use only fuels, lubricants, and coolants meeting specifications outlined in Fuels, Lubricants, and Coolant Section when servicing your John Deere Engine.

Consult your John Deere Servicing Distributor or your nearest John Deere Parts Network for recommended fuels, lubricants, and coolant. Also available are necessary additives for use when operating engines in tropical, arctic, or any other adverse conditions.



John Deere Parts

TS100 -JUN-23AUG88

RG.RG34710,5057 -19-30JAN98-1/1

Lubrication And Maintenance Service Interval Chart—Prime Power Engines

| Item | Lubrication and Maintenance Service Intervals | | | | |
|--|---|---------------------|----------------------|-----------------------|-------------|
| | Daily | 250 Hour or 6 Month | 500 Hour or 12 Month | 2000 Hour or 24 Month | As Required |
| Check Engine Oil and Coolant Level | • | | | | |
| Lubricate PTO Release Bearing | • | | | | |
| Check Air Cleaner Dust Unloader Valve & Restriction Indicator ^a | • | | | | |
| Visual Walk Around Inspection | • | | | | |
| Check Fuel Filter | • | | | | |
| Service Fire Extinguisher | | • | | | |
| Lubricate PTO Clutch Shaft Bearing | | • | | | |
| Service Battery | | • | | | |
| Change Engine Oil and Filter- All except 3029TF270 Engines ^b | | • | | | |
| Check Fan and Alternator Belt Tension | | • | | | |
| Check PTO Clutch Adjustment | | • | | | |
| Check Engine Mounts | | • | | | |
| Change Engine Oil and Filter- 3029TF270 Engines ^c | | | • | | |
| Check Engine Ground Connection | | | • | | |
| Lubricate PTO Clutch Levers and Linkage (If Equipped) | | | • | | |
| Clean Crankcase Vent Tube | | | • | | |
| Check Air Intake Hoses, Connections, and System | | | • | | |
| Replace Fuel Filter /Bleed System | | | • | | |
| Check Cooling System | | | • | | |
| Coolant Solution Analysis-Add SCAs as needed | | | • | | |
| Pressure Test Cooling System | | | • | | |
| Check Engine Speeds | | | • | | |
| Check and Adjust Valve Clearance | | | | • | |

^aReplace primary air cleaner element when restriction indicator shows a vacuum of 625 mm (25 in.) H₂O.

^bChange the oil and filter for the first time after 100 hours maximum of operation, then every 250 hours thereafter. If recommended oils are used along with the specified John Deere oil filter, the oil change interval may be extended by 50 percent to 375 hours. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant section.)

^cChange the oil for the first time before 100 hours maximum of (break-in) operation, then every 500 hours thereafter. If PLUS-50 or ACEA E7/E6/E5/E4 oil is NOT used along with the specified John Deere oil filter, the oil change interval is reduced to 250 hours. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant section for oil pan and fuel sulfur content restrictions.)

Lubrication and Maintenance

| Item | Lubrication and Maintenance Service Intervals | | | | |
|--|---|------------------------|-------------------------|--------------------------|-------------|
| | Daily | 250 Hour or 6 Month | 500 Hour or 12 Month | 2000 Hour or 24 Month | As Required |
| Flush and Refill Cooling System ^d | | | | • | |
| Test Thermostats | | | | • | |
| Add Coolant | | | | | • |
| Bleed Fuel System | | | | | • |
| Replace Air Cleaner Elements | | | | | • |
| Replace Belts | | | | | • |
| Inspect PTO Clutch (If Equipped) | | | | | • |
| Check Fuses | | | | | • |

^dIf John Deere COOL-GARD is used, the flushing and refilling interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished by adding supplemental coolant additives (SCAs), the flushing and refilling interval may be extended to 5000 hours or 60 months, whichever occurs first.

RG, RG34710, 5058 -19-30MAY06-2/2

Lubricant And Maintenance Service Interval Chart—Generator (Standby) Applications

NOTE: The service intervals in the Lubrication and Maintenance Sections that follow reflect standard engines. Use service intervals listed below for generator (standby) applications. Match service items below to titles in Lubrication and Maintenance Sections for procedures.

| Item | Lubrication and Maintenance Service Intervals | | | | |
|---|---|---------------------|----------------------|-----------------------|-------------|
| | Every 2 Weeks | 250 Hour or 6 Month | 500 Hour or 12 Month | 2000 Hour or 24 Month | As Required |
| Operate Engine at Rated Speed and 50%-70% Load a Minimum of 30 Minutes | • | | | | |
| Check Engine Oil and Coolant Level | • | | | | |
| Check Fuel Filter | • | | | | |
| Lubricate PTO Release Bearings | • | | | | |
| Check Air Cleaner Dust Unloader Valve & Restriction Indicator Gauge ^a | • | | | | |
| Visual Walkaround Inspection | • | | | | |
| Service Fire Extinguisher | | • | | | |
| Lubricate PTO Clutch Shaft Bearings | | • | | | |
| Service Battery | | • | | | |
| Change Engine Oil and Replace Oil Filter- All Except 3029TF270 Engines ^b | | • | | | |
| Check Fan and Alternator Belt Tension | | • | | | |
| Check PTO Clutch Adjustment | | • | | | |
| Check Engine Mounts | | • | | | |
| Change Engine Oil and Filter- 3029TF270 Engines ^c | | | • | | |
| Check Engine Ground Connection | | | • | | |
| Clean Crankcase Vent Tube | | | • | | |
| Check Air Intake Hoses, Connections & System | | | • | | |
| Replace Fuel Filter/Bleed System | | | • | | |
| Check Cooling System | | | • | | |
| Coolant Solution Analysis-Add SCAs as required | | | • | | |

^aReplace primary air cleaner element when restriction indicator shows a vacuum of 625 mm (25 in.) H2O.

^bChange the oil and filter for the first time after 100 hours maximum of operation, then every 250 hours thereafter. If recommended oils are used along with the specified John Deere oil filter, the oil change interval may be extended by 50 percent to 375 hours. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant section.)

^cChange the oil for the first time before 100 hours maximum of (break-in) operation, then every 500 hours thereafter. If PLUS-50 or ACEA E7/E6/E5/E4 oil is NOT used along with the specified John Deere oil filter, the oil change interval is reduced to 250 hours. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant section for oil pan and fuel sulfur content restrictions.)

Lubrication and Maintenance

| Item | Lubrication and Maintenance Service Intervals | | | | |
|--|---|---------------------|----------------------|-----------------------|-------------|
| | Every 2 Weeks | 250 Hour or 6 Month | 500 Hour or 12 Month | 2000 Hour or 24 Month | As Required |
| Pressure Test Cooling System | | | • | | |
| Check Engine Speeds | | | • | | |
| Adjust Variable Speed (Droop) | | | | • | |
| Check and Adjust Valve Clearance | | | | • | |
| Flush and Refill Cooling System ^d | | | | • | |
| Test Thermostats | | | | • | |
| Add Coolant | | | | | • |
| Bleed Fuel System | | | | | • |
| Replace Air Cleaner Elements | | | | | • |
| Replace Belts | | | | | • |
| Check Fuses | | | | | • |
| ^d If John Deere COOL-GARD is used, the flushing and refilling interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished by adding supplemental coolant additives, the flushing and refilling interval may be extended to 5000 hours or 60 months, whichever occurs first. | | | | | |

OUOD002,0000022 -19-26MAY06-2/2

Lubrication & Maintenance/Daily

Daily Prestarting Checks

Do the following **BEFORE STARTING THE ENGINE** for the first time each day:

Check Engine Oil Level


IMPORTANT: There is no need to add makeup oil until the oil level is **BELOW** the add mark.

DO NOT fill above the top mark on the dipstick. Oil levels anywhere within arrows (C) or crosshatch (D), whichever is present, are considered in the acceptable operating range.

1. Check engine oil level on dipstick (A). Oil level on dipstick should be within arrows (C) or crosshatch (D). Add oil at filler cap (B) as required, using seasonal viscosity grade oil. (See **DIESEL ENGINE OIL** in Fuels, Lubricants, and Coolant Section for oil specifications.)


Some engines may have the oil filler cap on rocker arm cover, while others will have the filler cap on the timing gear cover.

- A—Dipstick
- B—Oil Filler Cap
- C—Arrows
- D—Crosshatch




3029D Engines (Tier I Emission Certified Engine Shown)

RG11536 -UN-01DEC00




3029T Engines (Tier I Emission Certified Engine Shown)
RG11537 -UN-01DEC00

RG11595 -UN-08DEC00



Correct Oil Level Within Arrows
RG11538 -UN-01DEC00



Correct Oil Level Within Crosshatch

Continued on next page

RG,RG34710,5059 -19-11FEB03-1/5

Check Coolant Level

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Only remove filler cap when engine is cold or when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.


1. Check the coolant level when engine is cold. Coolant level should be at bottom of filler neck. Fill radiator (A) with proper coolant solution if level is low. (See **ADDING COOLANT** in Service As Required Section.) Check overall cooling system for leaks.

Refer to your vehicle's operator's manual for recommendations for non-John Deere supplied accessories.

A—Radiator



Beware of Hot Fluids Under Pressure



Coolant Level in Radiator

TSS281 -JUN-23AUG88

RG4675 -JUN-14DEC88


Continued on next page

RG, RG34710, 5059 -19-11FEB03-2/5

Lubricate PTO Bearing

1. Apply one shot of John Deere Multi-Purpose Lubricant or equivalent at PTO release bearing grease fitting (A). DO NOT over lubricate.

A—Grease Fitting



PTO Release Bearing

Continued on next page

RG, RG34710, 5059 -19-11FEB03-3/5

Check Air Cleaner

IMPORTANT: Maximum air intake restriction is 3.5 kPa (0.03 bar) (0.5 psi) (14 in.) H₂O. A clogged air cleaner element will cause excessive intake restriction and a reduced air supply to the engine.

1. Squeeze dust unloader valve (A) on air cleaner assembly to remove dust deposits. If clogged, remove and clean the dust unloader valve. Replace if damaged.

IMPORTANT: Do not operate engine without the dust unloader valve.

If equipped with air intake restriction indicator gauge (B), check gauge. Service air cleaner when indicator is red.

Inspect Engine Compartment

1. Make a thorough inspection of the engine compartment. Look for oil or coolant leaks, worn fan and accessory drive belts, loose connections and trash build-up. Remove trash build-up and have repairs made as needed if leaks are found.

NOTE: Wipe all fittings, caps, and plugs before performing any maintenance to reduce the chance of system contamination.

Inspect:


- Radiator for leaks and trash build-up.
- Air intake system hoses and connections for cracks and loose clamps.
- Fan, alternator, and accessory drive belts for cracks, breaks or other damage.
- Water pump for coolant leaks.

NOTE: It is normal for a small amount of leakage to occur as the engine cools down and parts contract. Excessive coolant leakage may indicate the need to replace the water pump seal. Contact your engine distributor or servicing dealer for repairs.



European Air Cleaner

RG11535 -JUN-01DEC00



North American Air Cleaner

RG7332 -JUN-06JAN99

A—Dust Unloader Valve
B—Restriction Indicator Gauge

Checking Fuel Filter

Check the fuel filter daily for water or debris and drain as necessary.


IMPORTANT: Drain water into a suitable container and dispose of properly.

1. Loosen drain plug (B) at bottom of fuel filter two or three turns.
2. Loosen air bleed plug (A) two full turns on fuel filter base and drain water from bottom until fuel starts to drain out.
3. When fuel starts to drain out, hand tighten drain plug.

After draining water from the fuel filter, the filter must be primed by bleeding all air from the fuel system.


4. Operate primer lever (C) of the fuel supply pump until fuel flow is free from air bubbles.
5. Tighten bleed plug (A) securely by hand. Continue operating hand primer until pumping action is not felt. When finished, pull hand primer outward (away from engine) as far as it will go.

If the fuel system needs further bleeding of air, see BLEED FUEL SYSTEM in Service As Required Section, later in this manual.



Draining the Fuel Filter

RG11539 -UN-01DEC00



Fuel Supply Pump Primer Lever

RG11540 -UN-01DEC00

- A—Bleed Plug
- B—Drain Plug
- C—Primer Lever

RG, RG34710, 5059 -19-11FEB03-5/5

Lubrication & Maintenance/250 Hour/6 Month

Servicing Fire Extinguisher

A fire extinguisher (A) is available from your authorized servicing dealer or engine distributor.

Read and follow the instructions which are packaged with it. The extinguisher should be inspected at least every 250 hours of engine operation or once a month. Once extinguisher is operated, no matter how long, it must be recharged. Keep record of inspections on the tag which comes with the extinguisher instruction booklet.

A—Fire Extinguisher



Service Fire Extinguisher

RW4918 -UN-15DEC88


RG, RG34710, 5062 -19-30JAN98-1/1

Lubricating PTO Clutch Shaft Bearings

Apply one or two shots of John Deere Multipurpose Lubricant or equivalent at clutch drive shaft bearing fitting (B) and pilot bearing fittings (D). DO NOT over-lubricate to avoid getting oil on clutch facings.

NOTE: Location of pilot bearing fitting will depend on application. Only one fitting will be used.

- A—Release Bearing Grease Fitting
- B—Drive Shaft Bearing Fitting
- C—Lever Cross Shaft Fittings
- D—Pilot Bearing Fitting



Lubricate PTO Clutch

RG7331C -UN-26JUN00

RG, RG34710, 5061 -19-30JAN98-1/1

Servicing Battery



CAUTION: Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded **NEGATIVE (—)** battery clamp first and replace it last.



Exploding Battery

TSS204 -JUN-23AUG88

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

1. On regular batteries, check electrolyte level. Fill each cell to bottom of filler neck with distilled water.

NOTE: Low-maintenance or maintenance-free batteries should require little additional service. However, electrolyte level can be checked by cutting the center section of decal on dash-line, and removing cell plugs. If necessary, add clean, soft water to bring level to bottom of filler neck.

2. Keep batteries clean by wiping them with a damp cloth. Keep all connections clean and tight. Remove any corrosion, and wash terminals with a solution of 1 part baking soda and 4 parts water. Tighten all connections securely.

NOTE: Coat battery terminals and connectors with a mixture of petroleum jelly and baking soda to retard corrosion.

3. Keep battery fully charged, especially during cold weather. If a battery charger is used, turn charger off before connecting charger to battery(ies). Attach **POSITIVE (+)** battery charger lead to **POSITIVE (+)** battery post. Then attach **NEGATIVE (—)** battery charger lead to a good ground.

Continued on next page

RG, RG34710, 7563 -19-13FEB03-1/2

CAUTION: Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Using proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10—15 minutes. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.



Sulfuric Acid

TS203 -JUN-23AUG88

In freezing weather, run engine at least 30 minutes to ensure thorough mixing after adding water to battery.

Replacement battery(ies) must meet or exceed the following recommended capacities¹ at -18°C (0°F):

Specification

| | |
|--------------------------------|-------------|
| 12-Volt System—Minimum | |
| Battery Capacity—Cold Cranking | |
| Amps..... | 640 Minimum |
| 24-Volt System—Minimum | |
| Battery Capacity—Cold Cranking | |
| Amps..... | 570 Minimum |

¹ Total recommended capacity based on batteries connected in series or parallel.

Changing Engine Oil And Replacing Oil Filter-All Except 3029TF270 Engines

NOTE: Change engine oil and filter for the first time after 100 hours maximum of operation, then every 250 hours thereafter.

If John Deere PLUS-50 engine oil **and** the specified John Deere oil filter are used, the oil and filter change interval may be increased by 50% to 375 hours.

OILSCAN is a John Deere sampling program to help you monitor machine performance and identify potential problems before they cause serious damage. OILSCAN kits are available from your John Deere dealer. Oil samples should be taken prior to the oil change. Refer to instructions provided with kit.

To change engine oil and filter:

1. Run engine approximately 5 minutes to warm up oil. Shut engine off.
2. Remove oil pan drain plug (arrow).

NOTE: Drain plug location may vary, depending on the application.

3. Drain crankcase oil from engine while warm.



Oil Pan Drain Plug

RG4881 -UN-29NOV88

Continued on next page

RG, RG34710, 5064 -19-13FEB03-1/3


- Remove and discard oil filter (A) using a suitable filter wrench.

NOTE: Depending on engine application, oil filter may be either vertical or horizontal on either engine model.

- Remove oil filter packing and clean filter mounting pad.
- Oil new packing and install new filter element. Hand tighten element according to values printed on filter element. If values are not provided, tighten element approximately 3/4—1-1/4 turn after packing contacts filter housing. **DO NOT** overtighten filter element.
- Install oil pan drain plug with a new seal when equipped and tighten using the following specifications.


| | |
|--|-------------------|
| Conical Plug | 55 N•m (41 lb-ft) |
| Cylindrical Plug W/Copper Washer | 70 N•m (52 lb-ft) |
| Cylindrical Plug W/O-Ring | 50 N•m (37 lb-ft) |

A—Oil Filter




Engine Mounted Oil Filter

RG11529 -UN-01DEC00



Engine Mounted Oil Filter

RG11530 -UN-01DEC00



Engines W/Remote Oil Filter

RG11549 -UN-06DEC00

Continued on next page

RG,RG34710,5064 -19-13FEB03-2/3

- Fill engine crankcase with correct John Deere engine oil through timing gear cover opening (A) or rocker arm cover opening (B), depending on engine application. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant Section for determining correct engine oil.)


NOTE: Crankcase oil capacity may vary slightly. ALWAYS fill crankcase to top arrow or within crosshatch on dipstick, whichever is present. This should be checked after engine has run and oil has drained back into crankcase. DO NOT overfill.

To determine the correct oil fill quantity for your engine, see ENGINE CRANKCASE OIL FILL QUANTITIES in the Specifications Section.

IMPORTANT: Immediately after completing any oil change, crank engine for 30 seconds without permitting engine to start. This will help insure adequate lubrication to engine components before engine starts.


- Start engine and run to check for possible leaks.
- Stop engine and check oil level after 10 minutes. Oil level reading should be between arrows (C) or within crosshatch (D) of dipstick.

- A—Timing Gear Cover Opening
- B—Rocker Arm Cover Opening
- C—Arrows
- D—Crosshatch



Timing Gear Cover Oil Fill


RG11541 -UN-01DEC00



Rocker Arm Cover Oil Fill


RG11537 -UN-01DEC00

RG11596 -UN-08DEC00



Correct Oil Level Within Arrows

RG11538 -UN-01DEC00



Correct Oil Level Within Crosshatch

RG, RG34710, 5064 -19-13FEB03-3/3

Checking Fan And Alternator V-Belt Tension

Low belt tension causes slippage resulting in excessive cover wear, burn spots, overheating, or "slip and grab", causing belt breakage.

High belt tension causes belt heating and excessive stretch, as well as damage to drive components such as pulleys and shafts. V-belts should ride on the sides of standard pulleys not on the bottom of the groove.

Continued on next page

RG, RG34710, 5065 -19-30JAN98-1/3

Standard V-belt tension can be checked with JDG529 Tension Gauge (bold arrow) or equivalent gauge. (Gauge is available from a John Deere Dealer or Distributor)


NOTE: On engines with dual belts, check tension of front belt only.

1. Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary.
2. Using JDG529 Belt Tension Gauge, or belt tension tester (A) and straightedge (B), check tension of warm belts:
 - a. When using JDG529 Belt Tension Gauge, measure belt tension and compare with specifications on next page.
 - b. Belt deflection when using belt tension tester (A) with straightedge (B), with force applied halfway between pulleys.

Specification


Standard V-Belt with 89 N (20 lb)
force—Deflection 19 mm (3/4 in.)

A—Tension Tester
B—Straightedge



Checking Belt Tension with Tension Gauge

RG7333 -UN-01DEC00



Checking Belt Tension with Straightedge

RG7334 -UN-01DEC00


Continued on next page

RG, RG34710, 5065 -19-30JAN98-2/3

- If adjustment is necessary, loosen alternator bracket cap screw (C) and nut (D) on mounting bolt. Pull alternator frame outward until belts are correctly tensioned.

IMPORTANT: Do not pry against the alternator rear frame. Do not tighten or loosen belts while they are hot.

- Tighten alternator bracket cap screw and nut firmly.
- After a new or used belt has run for 10 minutes, recheck belt tension.



Alternator Mounting Brackets

C—Cap Screw
D—Nut

STANDARD V-BELTS

| | New Belt Tension | Used Belt Tension^a |
|-------------|------------------------------|--------------------------------------|
| Single Belt | 578—623 N (130—140 lb force) | 378—423 N (85—95 lb force) |
| Dual Belts | 423—463 N (95—104 lb force) | 378—423 N (85—95 lb force) |

^aBelts are considered used after 10 minutes of operation.

RG7329 -UN-01DEC00

RG, RG34710, 5065 -19-30JAN98-3/3

Checking PTO Clutch Adjustment

CAUTION: Never attempt to service the PTO while it is in operation. Loose clothing could get caught in moving parts; keep clothing tight against body. Use extreme care when working around the PTO.


1. Measure clutch engagement force at handle grip using a spring scale. The engagement force should be 267–311 N (60–70 lb force).

IMPORTANT: Improper adjustments of the PTO clutch may shorten clutch life. Make sure adjustments are made properly.

2. If adjustments are needed, disengage clutch and stop engine. Remove cover plate from clutch housing (shown removed).
3. Remove adjusting lock (A).
4. Turn adjusting ring (B) to adjust clutch engagement pressure.
5. Measure engagement force at clutch handle with spring scale.
6. Install lock screw and adjusting lock in clutch body splines when specified engagement pressure is achieved.
7. Tighten screw securely.
8. Recheck clutch engagement force with spring scale. Install cover plate. Disengage clutch.



Rotating Driveline



PTO Clutch Adjustment

A—Adjusting Lock
B—Adjusting Ring

T5198 -JUN-23AUG88

R27550 -JUN-14DEC88

Checking Engine Mounts

Engine mounting is the responsibility of the vehicle or generator manufacturer. Follow manufacturer's guidelines for mounting specifications.

IMPORTANT: Use only Grade SAE 8 or higher grade of hardware for engine mounting.

1. Check the engine mounting bracket, vibration isolators, and mounting bolts on support frame and engine block for tightness. Tighten as necessary.
2. Inspect overall condition of vibration isolators, if equipped. Replace isolators if rubber has deteriorated or mounts have collapsed, as necessary.

DPSG, RG34710, 111 -19-07JAN02-1/1

Lubrication & Maintenance/500 Hour/12 Month

Changing Engine Oil And Replacing Oil Filter—3029TF270 Engines Only

Your engine is equipped with a special oil filter (A).

NOTE: During break-in, change engine oil and filter for the first time before 100 hours maximum of operation.

After break-in, if John Deere PLUS-50™ or ACEA-E7/E6/E5/E4 engine oil **and** a John Deere special oil filter are used, the oil and filter change interval is 500 hours or every 12 months, whichever comes first.

NOTE: If the above recommendations are not followed, the oil and filter change interval is every 250 hours/ or 6 months. If diesel fuel with a high sulfur content is used, the oil and filter change interval is also reduced. (See DIESEL ENGINE OIL in the "Fuels, Lubricants, and Coolant" Section.)

OILSCAN™ or OILSCAN PLUS™ is a John Deere sampling program to help you monitor machine performance and identify potential problems before they cause serious damage. OILSCAN™ and OILSCAN PLUS™ kits are available from your John Deere engine distributor or servicing dealer. Oil samples should be taken prior to the oil change. Refer to instructions provided with kit.

To change engine oil and oil filter:

1. Run engine approximately 5 minutes to warm up oil. Shut engine off.
2. Remove oil pan drain plug (arrow).

NOTE: Drain plug location may vary, depending on the application.

3. Drain crankcase oil from engine while warm.



Special Oil Filter



Oil Pan Drain Plug

A—Oil Filter Element

RG11616 -JUN-24OCT01

RG4881 -JUN-29NOV88

PLUS-50 is a trademark of Deere & Company.
OILSCAN is a trademark of Deere & Company.
OILSCAN PLUS is a trademark of Deere & Company.

Continued on next page

OUOD005,00001D7 -19-30MAY06-1/3


- Remove and discard oil filter (A) using a suitable filter wrench.

NOTE: Depending on engine application, oil filter may be either vertical or horizontal on either engine model.

- Remove oil filter packing and clean filter mounting pad.
- Oil new packing and install new filter element. Hand tighten element according to values printed on filter element. If values are not provided, tighten element approximately 3/4—1-1/4 turn after packing contacts filter housing. **DO NOT** overtighten filter element.
- Install oil pan drain plug with a new seal when equipped and tighten using the following specifications.


| | |
|--|-------------------|
| Conical Plug | 55 N•m (41 lb-ft) |
| Cylindrical Plug W/Copper Washer | 70 N•m (52 lb-ft) |
| Cylindrical Plug W/O-Ring | 50 N•m (37 lb-ft) |

A—Oil Filter




Engine Mounted Oil Filter

RG11529 -UN-01DEC00



Engine Mounted Oil Filter

RG11530 -UN-01DEC00



Engines W/Remote Oil Filter

RG11549 -UN-06DEC00

Continued on next page

OJOD005,00001D7 -19-30MAY06-2/3

- Fill engine crankcase with correct John Deere engine oil through timing gear cover opening (A) or rocker arm cover opening (B), depending on engine application. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant Section for determining correct engine oil.)


NOTE: Crankcase oil capacity may vary slightly. ALWAYS fill crankcase to top arrow or within crosshatch on dipstick, whichever is present. This should be checked after engine has run and oil has drained back into crankcase. DO NOT overfill.

To determine the correct oil fill quantity for your engine, see ENGINE CRANKCASE OIL FILL QUANTITIES in the Specifications Section.

IMPORTANT: Immediately after completing any oil change, crank engine for 30 seconds without permitting engine to start. This will help insure adequate lubrication to engine components before engine starts.


- Start engine and run to check for possible leaks.
- Stop engine and check oil level after 10 minutes. Oil level reading should be between arrows (C) or within crosshatch (D) of dipstick.

- A—Timing Gear Cover Opening
- B—Rocker Arm Cover Opening
- C—Arrows
- D—Crosshatch



Timing Gear Cover Oil Fill


RG11541 -UN-01DEC00



Rocker Arm Cover Oil Fill


RG11537 -UN-01DEC00

RG11596 -UN-08DEC00



Correct Oil Level Within Arrows

RG11538 -UN-01DEC00



Correct Oil Level Within Crosshatch

OJOD005,00001D7 -19-30MAY06-3/3

Lubricating PTO Clutch Internal Levers And Linkage


CAUTION: Never attempt to service the PTO while it is in operation. Loose clothing could get caught in moving parts; keep clothing tight against body. Use extreme care when working around the PTO.

1. Remove the PTO housing cover and apply one shot of John Deere Multipurpose Lubricant or equivalent (See FUELS, LUBRICANTS, and COOLANT Section) to the pivot points (A) of each clutch linkage.
2. Apply one shot of John Deere Multipurpose Lubricant or equivalent to the two PTO release lever shaft fittings (B).

A—Pivot Points
B—Fittings



Use Extreme Care When Working Around the PTO



Lubrication Internal Parts of PTO Clutch

TS198 -UN-23AUG88

RG6641 -UN-18FEB93


RG, RG34710, 5068 -19-30JAN98-1/1

Cleaning Crankcase Vent Tube

If you operate the engine in dusty conditions, clean the tube at shorter intervals.

1. Remove and clean crankcase vent tube (A).
2. Install the vent tube. Be sure the tube is not pinched and O-ring fits correctly in the rocker arm cover for elbow adapter. Tighten hose clamp securely.

A—Vent Tube



Crankcase Vent Tube

RG6005 -UN-27JAN92

RG, RG34710, 5069 -19-30JAN98-1/1

Checking Air Intake System

IMPORTANT: The air intake system must not leak. Any leak, no matter how small, may result in engine failure due to abrasive dirt and dust entering the intake system.

1. Inspect all intake hoses (piping) for cracks. Replace as necessary.
2. Check clamps (A) on piping which connect the air cleaner, engine, and, if present, turbocharger. Tighten clamps as necessary. This will help prevent dirt from entering the air intake system through loose connections causing internal engine damage.
3. If engine has a rubber dust unloader valve (B), inspect the valve on bottom of air cleaner for cracks or plugging. Replace as necessary.


IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator is red or shows a vacuum of at least 3.5 kPa (14 in.) H₂O, is torn, or visibly dirty.

4. Test air restriction indicator (C) for proper operation. Replace indicator as necessary.

IMPORTANT: If not equipped with air restriction indicator, replace air cleaner elements at 500 Hours or 12 Months, whichever occurs first.


5. Remove and inspect primary air cleaner element. Service as necessary. (See INSPECTING PRIMARY FILTER ELEMENT and REPLACING AIR CLEANER ELEMENTS in Service As Required Section.)

A—Clamps
B—Unloader Valve
C—Restriction Indicator




Air Cleaner Clamps

RG4689 -UN-20DEC88



North American Air Cleaner

RG11067 -UN-05JUN00




European Air Cleaner

RG11542 -UN-01DEC00

Replacing Fuel Filter/Bleeding System

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.



Beware of High-Pressure Fluids


X9811 -UN-23AUG88

If any fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

1. Close fuel shut-off valve at tank, if equipped.
2. Thoroughly clean fuel filter assembly and surrounding area.
3. Loosen filter drain plug (C) and air bleed plug (D). Drain fuel into a suitable container. Dispose of fuel in an environmentally safe manner.

NOTE: Lifting up on retaining ring as it is rotated helps to get it past raised locators.

4. Firmly grasp the retaining ring (A), lift up and rotate it clockwise 1/4 turn. Remove ring with filter element (B).
5. Save retaining ring and (if equipped) water separator bowl for reuse.
6. Remove red plug from new filter and install into removed filter to protect the environment from leaking fuel.
7. Inspect filter mounting base for cleanliness. Clean as required.



Fuel Filter


- A—Retaining Ring
- B—Filter Element
- C—Filter Drain Plug
- D—Air Bleed Plug

RG11543 -UN-01DEC00

8. Inspect condition of dust seal (C). Replace if necessary. Install dust seal as shown.

NOTE: Proper installation is indicated when a "click" is heard and a release of pressure on the ring is felt.

9. Align keys on filter element with slots in filter base, then tighten retaining ring counterclockwise 1/4 turn until it "snaps" into the detent. DO NOT overtighten.
10. If equipped with water separator, remove water separator bowl from removed filter element. Drain and clean separator bowl. Dry with compressed air. Install water separator bowl onto new element. Tighten securely.
11. Leave fuel shut-off valve open and bleed the fuel system. (See BLEED FUEL SYSTEM in Service As Required Section.) Tighten bleed plug.



A—Correct Installation
 B—Incorrect Installation
 C—Seal

RG9187 -JUN-01DEC00

RG.RG34710,5071 -19-13FEB03-2/2

Checking Cooling System

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head to allow air to escape when filling system. Retighten fitting when all the air has been expelled.

1. Check entire cooling system for leaks. Tighten all clamps securely.
2. Thoroughly inspect all cooling system hoses. Replace hoses when hardened, softened, or cracked.
3. If coolant must be added, use mixture as recommended in Fuels, Lubricants and Coolant section.



Beware of Pressurized Fluids

TSS281 -JUN-23AUG88

RG, RG34710, 5073 -19-30JAN98-1/1

Testing Diesel Engine Coolant

Testing Diesel Engine Coolant

Maintaining adequate concentrations of glycol and inhibiting additives in the coolant is critical to protect the engine and cooling system against freezing, corrosion, and cylinder liner erosion and pitting.

Test the coolant solution at intervals of 12 months or less and whenever excessive coolant is lost through leaks or overheating.

Coolant test strips

Coolant test strips are available from your John Deere dealer. These test strips provide a simple, effective

method to check the freeze point and additive levels of your engine coolant.

Compare the results to the supplemental coolant additive (SCA) chart to determine the amount of inhibiting additives in your coolant and whether more John Deere COOLANT CONDITIONER should be added.

COOLSCAN™ and COOLSCAN PLUS™

For a more thorough evaluation of your coolant, perform a COOLSCAN or COOLSCAN PLUS analysis, where available. See your John Deere dealer for information.

COOLSCAN is a trademark of Deere & Company
COOLSCAN PLUS is a trademark of Deere & Company

DX,COOL9 -19-19DEC03-1/1

Replenishing Supplemental Coolant Additives (SCAs) Between Coolant Changes

IMPORTANT: Do not add supplemental coolant additives when the cooling system is drained and refilled with John Deere ANTIFREEZE/SUMMER COOLANT or COOL-GARD™.

NOTE: If system is to be filled with coolant that does not contain SCAs, the coolant must be precharged. Determine the total system capacity and premix with 3% John Deere Coolant Conditioner.


Through time and use, the concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere ANTIFREEZE/SUMMER COOLANT is used. The cooling system must be recharged with additional supplemental coolant additives available in the form of liquid coolant conditioner.

Maintaining the correct coolant conditioner concentration (SCAs) and freeze point is essential in your cooling system to protect against rust, liner pitting and corrosion, and freeze-ups due to incorrect coolant dilution.


John Deere LIQUID COOLANT CONDITIONER is recommended as a supplemental coolant additive in John Deere engines.

DO NOT mix one brand of SCA with a different brand.

Test the coolant solution at 500 hours or 12 months of operation using either John Deere coolant test strips or a COOLSCAN™ analysis. If a COOLSCAN™ analysis is not available, recharge the system per instructions printed on label of John Deere Liquid Coolant Conditioner.



Radiator Coolant Check



JTO7298 Coolant/Battery Tester

COOL-GARD is a trademark of Deere & Company
COOLSCAN is a trademark of Deere & Company

Continued on next page

DPSG,OUOD002,1921 -19-09OCT02-1/2

IMPORTANT: ALWAYS maintain coolant at correct level and concentration. DO NOT operate engine without coolant even for a few minutes.

If frequent coolant makeup is required, the glycol concentration should be checked with JTO7298 Coolant/Battery Tester to ensure that the desired freeze point is maintained. Follow manufacturer's instructions provided with Coolant/Battery Tester.

Add the manufacturer's recommended concentration of supplemental coolant additive. DO NOT add more than the recommended amount.


The use of non-recommended supplemental coolant additives may result in additive drop-out and gelation of the coolant.

If other coolants are used, consult the coolant supplier and follow the manufacturer's recommendation for use of supplemental coolant additives.

See DIESEL ENGINE COOLANTS AND SUPPLEMENTAL ADDITIVE INFORMATION for proper mixing of coolant ingredients before adding to the cooling system.


DPSG.OUOD002.1921 -19-09OCT02-2/2

Pressure Testing Cooling System



Pressure Testing Radiator Cap

RG6657 -JUN-20JAN93



Pressure Testing Cooling System

RG6658 -JUN-20JAN93

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

Test Radiator Cap

1. Remove radiator cap and attach to D05104ST Tester as shown.
2. Pressurize cap to following specifications.¹ Gauge should hold pressure for 10 seconds within the normal range if cap is acceptable.

Specification

Radiator Cap—Test Pressure 70 kPa (0.7 bar (10 psi))

If gauge does not hold pressure, replace radiator cap.

3. Remove the cap from gauge, turn it 180°, and retest cap. This will verify that the first measurement was accurate.

Test Cooling System

NOTE: Engine should be warmed up to test overall cooling system.

1. Allow engine to cool, then carefully remove radiator cap.
2. Fill radiator with coolant to the normal operating level.

IMPORTANT: DO NOT apply excessive pressure to cooling system, doing so may damage radiator and hoses.

3. Connect gauge and adapter to radiator filler neck. Pressurize cooling system to the following specifications¹.

Specification

Cooling System—Test Pressure 70 kPa (0.7 bar (10 psi))

4. With pressure applied, check all cooling system hose connections, radiator, and overall engine for leaks.

¹Test pressures recommended are for all Deere OEM cooling systems. On specific vehicle applications, test cooling system and pressure cap according to the recommended pressure for that vehicle.

If leakage is detected, correct as necessary and pressure test system again.

If no leakage is detected, but the gauge indicated a drop in pressure, coolant may be leaking internally

within the system or at the block-to-head gasket. Have your servicing dealer or distributor correct this problem immediately.

RG, RG34710, 5078 -19-20FEB03-2/2

Checking and Adjusting Engine Speeds

Observe tachometer reading (A) on the instrument panel to verify engine speeds. (Refer to ENGINE POWER AND SPEED SPECIFICATIONS in Specifications Section later in this manual for engine speed specifications.)




RG12831 -UN-13FEB03

North American Instrument Panel Tachometer



RG12832 -UN-13FEB03

AEZ Instrument Panel Tachometer



RG12830 -UN-13FEB03

VDO Instrument Panel Tachometer

OUOD005,00001D8 -19-20FEB03-1/1


Lubrication & Maintenance/2000 Hour/24 Month

Adjusting Variable Speed (Droop) On Generator Set Engines (Stanadyne Injection Pumps Only)

CAUTION: Statutes providing severe penalties for tampering with emissions controls may apply at the user's location.


1. Warm engine to normal operating temperature.
2. If necessary, disconnect throttle linkage or cable.
3. Run engine at fast idle. Check and adjust fast idle speed when necessary.
4. Apply full load.
5. Check power. Adjust with knob or screw (A) if needed.
6. Remove load.
7. Check and adjust fast idle if knob or screw (A) has been turned.
8. Repeat procedure until both the engine power and fast idle speed are correct.
9. Connect throttle linkage if previously removed.

A—Screw



Droop Adjusting Knob

T86735 -UN-23FEB89



Droop Adjusting Screw

RG8418 -UN-01DEC00

RG, RG34710, 5076 -19-30JAN98-1/1

Checking And Adjusting Engine Valve Clearance

CAUTION: To prevent accidental starting of engine while performing valve adjustments, always disconnect **NEGATIVE (-)** battery terminal.

IMPORTANT: Engine valve clearance **MUST BE** checked and adjusted with engine **COLD**.

1. Remove rocker arm cover and crankcase ventilator tube.

IMPORTANT: Visually inspect contact surfaces of wear caps and rocker arm wear pads. Check all parts for excessive wear, breakage, or cracks. Replace parts that show visible damage.

Rocker arms with excessive valve clearance should be inspected more thoroughly to identify damaged parts.

2. Using JDE83 or JDG820 Flywheel Turning Tool, rotate engine flywheel in running direction (clockwise viewed from front of engine) until JDG1571 (or JDE81-4) timing pin goes into flywheel hole. Check if Number 1 is at compression stroke (B). (No. 1 rocker arms should be loose.) If not, rotate engine one full revolution (360°) until timing pin goes into flywheel hole.


NOTE: Firing order is 1-2-3.

3. Check and adjust valve clearance using a feeler gauge on No. 1 and 2 exhaust valves and No. 1 and 3 intake valves.


Specification

Valve Clearance (Engine Cold)—

Specification—Intake 0.35 mm (0.014 in.)
 Exhaust..... 0.45 mm (0.018 in.)



Checking Valve Clearance



Valve Adjusting Order

- A—Front of Engine
- B—Number 1 Piston at TDC Compression Stroke
- C—Number 1 Piston at TDC Exhaust Stroke
- E—Exhaust Valve
- I—Intake Valve

T81224 -UN-07NOV88

RG4775 -UN-06DEC88


NOTE: If rocker arm is equipped with adjusting screw and lock nut, tighten lock nut to specification after adjusting valve clearance.

Specification

Rocker Arm Adjusting Screw
 Lock Nut—Specification—Torque 27 N•m (20 lb-ft)

4. Rotate flywheel 360° and lock No. 1 piston at “TDC” exhaust stroke (C).
5. Check and adjust valve clearance on No. 3 exhaust valve and No. 2 intake valve.
6. Reinstall rocker arm cover and crankcase vent tube.

- A—Front of Engine
- B—Number 1 Piston at TDC Compression Stroke
- C—Number 1 Piston at TDC Exhaust Stroke
- E—Exhaust Valve
- I—Intake Valve



RG4775 -UN-06DEC88

RG.RG34710,5067 -19-18FEB03-2/2

Flushing And Refilling Cooling System

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

NOTE: Drain the initial factory fill engine coolant after the first 2000 hours or 24 months of operation. Subsequent drain intervals are determined by the coolant used for service.

When John Deere COOL-GARD™ is used, the drain interval is 3000 hours or 36 months. The drain interval may be extended to 5000 hours or 60 months of operation **provided that the coolant is tested annually AND additives are replenished as needed, by adding a supplemental cooling additive (SCA).**

If COOL-GARD™ is not used, the drain interval is reduced to 2000 hours or 24 months of operation.


Drain old coolant, remove thermostat, flush the entire cooling system, install thermostat, and fill with recommended clean coolant. For correct coolant mixture, refer to Fuels, Lubricants and Coolant section.

Perform these procedures as follows:

1. Pressure test entire cooling system and pressure cap if not previously done. (See PRESSURE TESTING COOLING SYSTEM, earlier in this section.)
2. Slowly open the engine cooling system filler cap or radiator cap (A) to relieve pressure and allow coolant to drain faster.



Beware of High Pressure Fluids



Radiator Cap


TSS281 -UN-23AUG88

RG12833 -UN-13FEB03

3. Open engine block drain valve or plug (A) on left side of engine. Drain all coolant from engine block.
4. Open radiator drain valve. Drain all coolant from radiator.
5. Remove thermostat at this time, if not previously done. Install cover (B) (without thermostat) and tighten cap screws to specification.

Specification

Capscrews—Torque..... 47 N•m (35 lb ft)




RG7315 -UN-01DEC00

Engine Block Drain Valve

6. Test thermostat opening temperature. (See TESTING THERMOSTAT OPENING TEMPERATURE following in this Section.)
7. Close all drain valves after coolant has drained.

CAUTION: Do not run engine longer than 5 minutes (at low idle) with water as coolant. Doing so may cause engine to overheat which may cause burns when water is draining.



RG11597 -UN-08DEC00

Thermostat Housing

8. Fill the cooling system with clean water. Run the engine about 5 minutes at low idle to stir up possible rust or sediment.
9. Stop engine, pull off lower radiator hose and remove radiator cap to immediately drain the water from the system before rust and sediment settle.
10. After draining water, close drain valves. Install radiator cap, radiator hose and clamp. Fill the cooling system with clean water and a heavy duty cooling system cleaner such as FLEETGUARD® RESTORE™ or RESTORE PLUS™. Follow manufacturer's directions on label.

A—Plug
B—Cover


FLEETGUARD is a trademark of Cummins Engine Company, Inc.
RESTORE is a trademark of Fleetguard Inc.
RESTORE PLUS is a trademark of Fleetguard Inc.

Continued on next page

RG, RG34710, 5079 -19-11FEB03-2/3

11. After cleaning the cooling system, drain cleaner and fill with water to flush the system. Run the engine about 5 minutes, remove radiator cap and pull off lower radiator hose, immediately draining out flushing water.

IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head to allow air to escape when filling system. Retighten fitting when all the air has been expelled.



Jiggle Wire

A—Jiggle Wire

RG11605 -JUN-24JAN01

12. Close all drain valves on engine and radiator. Install lower radiator hose and tighten clamp.

NOTE: Install thermostat with jiggle wire (A) at top position.

13. Install thermostat and cover using a new gasket. Tighten cap screws to specification.

Specification

Capscrews—Torque 47 N•m (35 lb ft)

14. Refill system with fresh coolant at radiator until coolant touches bottom of filler neck¹. (See ADDING COOLANT in Service As Required Section.)
15. Run engine until it reaches operating temperature. This mixes the solution uniformly and circulates it through the entire system. The normal engine coolant temperature range is 82°–94°C (180°–202°F).
16. After running engine, check coolant level and entire cooling system for leaks.

¹Cooling system capacity for the Saran-sourced 3029 L engine factory generator set package is 12 L (11.5 qt). Refer to OEM manufacturer for capacities of cooling systems not supplied by John Deere.

Testing Thermostat Opening Temperature

1. Remove thermostat.
2. Visually inspect thermostat for corrosion or damage.

CAUTION: DO NOT allow thermostat or thermometer to rest against the side or bottom of container when heating water. Either may rupture if overheated.


3. Suspend thermostat and a thermometer in a container of water.
4. Stir the water as it heats. Observe opening action of thermostat and compare temperatures with specification given in chart below.

NOTE: Due to varying tolerances of different suppliers, initial opening and full open temperatures may vary slightly from specified temperatures.

THERMOSTAT TEST SPECIFICATIONS

| Rating | Initial Opening (Range) | Full Open (Nominal) |
|--------------|-------------------------|---------------------|
| 82°C (180°F) | 80-84°C (175-182°F) | 94°C (202°F) |

5. Remove thermostat and observe its closing action as it cools. In ambient air the thermostat should close completely. Closing action should be smooth and slow.
6. Replace thermostat if opening temperature is not within specification.



Testing Thermostats


RG5971 -JUN-23NOV97

RG, RG34710, 5083 -19-30JAN98-1/1

Service As Required

Additional Service Information

This is not a detailed service manual. If you want more detailed service information, see John Deere Service Literature Available later in this manual to order the Component Technical Manuals for "Repair" and "Operation and Diagnosis".



John Deere Service Manuals

RG4624 -UN-15DEC88

RG, RG34710, 5080 -19-30JAN98-1/1

Do Not Modify Fuel System


IMPORTANT: Modification or alteration of the injection pump, the injection pump timing, or the fuel injectors in ways not recommended by the manufacturer will terminate the warranty obligation to the purchaser.

In addition, tampering with fuel system which alters emission-related equipment on engines may result in fines or other penalties, per EPA regulations or other local emission laws.

Do not attempt to service injection pump or fuel injectors yourself. Special training and special tools are required. (See your authorized servicing dealer or engine distributor.)



T81389 -19-



Fuel Injection Pump

RG11546 -UN-01DEC00

RG, RG34710, 5081 -19-30JAN98-1/1

Adding Coolant

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Never pour cold liquid into a hot engine, as it may crack cylinder head or block. NEVER operate engine without coolant.

John Deere TY15161 Cooling System Sealer may be added to the radiator to stop leaks on a temporary or emergency basis only. DO NOT use any other stop-leak additives in the cooling system. Leaks should be permanently repaired as quickly as possible.

Air must be expelled from cooling system when coolant is added.

1. Loosen temperature sending unit fitting (A) at rear of cylinder head to allow air to escape when filling system.


IMPORTANT: When adding coolant to the system, use the appropriate coolant solution. (See **ENGINE COOLANT SPECIFICATIONS** in Fuels, Lubricants, and Coolant Section for mixing of coolant ingredients before adding to cooling system.)

Do not overfill cooling system. A pressurized system needs space for heat expansion without overflowing at top of radiator.

2. Fill until coolant level touches bottom of radiator filler neck.
3. Tighten fitting when air has been expelled from system.



High Pressure Fluids



Coolant Temperature Sending Unit Fitting


A—Sending Unit Fitting

TSS281 -JUN-23AUG88

RG11607 -JUN-25JAN01

Bleeding The Fuel System

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.



Keep Skin Away from High Pressure Fluids

X9811 -UN-23AUG88

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.


IMPORTANT: Do not operate the engine at high speeds or full loads just before bleeding the fuel system as this may cause fuel injection pump failure.

Bleed the fuel system anytime the fuel system has been opened up. This includes:

- After fuel filter changes.
- After pump or nozzle replacement.
- Anytime fuel lines have been disconnected.
- After engine has run out of fuel.


Bleed the fuel system using the following procedure:

1. Loosen the air bleed vent screw (A) two full turns.
2. On mechanical supply pumps, operate supply pump primer lever (B) until fuel flow is free from air bubbles.
3. On electric supply pumps, turn key switch to "ON" position until fuel flow is free from air bubbles.
4. Tighten bleed plug securely by hand. Continue operating hand primer until pumping action is not felt. When finished, pull hand primer outward (away from engine) as far as it will go.



Fuel Filter Air Bleed Vent Screw

RG11544 -UN-01DEC00



Fuel Supply Pump Primer Lever

RG11545 -UN-01DEC00

A—Vent Screw
B—Primer Lever


5. Start engine and check for leaks.

If engine will not start, it may be necessary to bleed air from fuel system at fuel injection pump or injection nozzles as explained next.

RG, RG34710, 5084 -19-13FEB03-2/4

At Fuel Injection Pump

1. Slightly loosen fuel supply line connector (A) at injection pump.
2. On mechanical supply pumps, operate fuel supply pump primer lever until fuel, without air bubbles, flows from fuel line connection.
3. On electric supply pumps, turn key switch to "ON" position until fuel, without air bubbles, flows from fuel line connection.
4. Tighten fuel supply line connector to specification.



RG7316 -UN-01DEC00

Fuel Supply Line Connector at Injection Pump

A—Connector

Specification

Connector—Torque 16 N•m (12 lb ft)

5. Leave hand primer in the outward position away from cylinder block.

Continued on next page

RG, RG34710, 5084 -19-13FEB03-3/4

At Fuel Injection Nozzles

1. Move the speed control lever to half throttle position. On engines equipped with electronic fuel shut-off solenoid, energize solenoid.
2. Using two open-end wrenches, loosen fuel line connection at injection nozzle.
3. Crank engine over with starting motor, (but do not start engine), until fuel free from air bubbles flows out of loosened connection. Tighten connection to specification.



T92924 -UN-01NOV88

Bleeding Fuel System at Injection Nozzle

Specification

Connection—Torque..... 27 N•m (20 lb ft)

4. Repeat procedure for remaining injection nozzles (if necessary) until all air has been removed from fuel system.


If engine still will not start, see your authorized servicing dealer or engine distributor.

RG.RG34710,5084 -19-13FEB03-4/4

Replacing Air Cleaner Filter Elements

IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of at least 3.5 kPa (14 in.) of H₂O, is torn, or visibly dirty.

NOTE: This procedure applies to John Deere air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.




RG4686 -UN-20DEC88

Air Cleaner Primary Element (North American)

North American Air Cleaners

1. Remove wing nut and remove canister cover shown in small illustration inset.
2. Remove wing nut (A) and remove primary element (B) from canister.
3. Thoroughly clean all dirt from inside canister.

NOTE: Some engines may have a dust unloader valve (C) on the air cleaner. If equipped, squeeze valve tip to release any trapped dirt particles.




Dust Unloader Valve

RG4687 -UN-20DEC88

IMPORTANT: Remove secondary (safety) element (E) ONLY for replacement. DO NOT attempt to clean, wash, or reuse secondary element. Replacement of secondary element is usually necessary ONLY when primary element has a hole in it.

4. To replace secondary element, remove retaining nut (D) and secondary element (E). Immediately replace secondary element with new element to prevent dust from entering air intake system.
5. Install new primary element and tighten wing nut securely. Install cover assembly and tighten retaining wing nut securely.



RG11068 -UN-26JUN00

Air Cleaner Secondary Element

- A—Wing Nut
- B—Primary Element
- C—Unloader Valve
- D—Retaining Nut
- E—Secondary Element

Continued on next page

DPSG,OUOD002,1580 -19-30MAY06-1/2

IMPORTANT: Whenever the air cleaner has been serviced or had cover removed, **ALWAYS** fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.

6. If equipped, fully depress air restriction indicator reset button and release to reset indicator.


On European Sourced Air Cleaner Kits:

Clean filter element when air restriction indicator (A) or (G) is red. Replace filter element every 6 cleanings or once every 12 months.

NOTE: On light-duty air cleaner, loosen clamp (F) and remove light-duty filter element (E).


1. Remove cover (B).
2. Remove filter element (C).
3. Thoroughly clean all dirt from inside filter housing.
4. Squeeze dust unloader valve (D) to remove dust deposits. If clogged, remove and clean the dust unloader valve. Replace if damaged.
5. Clean filter element using compressed air.
6. Reinstall the filter element and cover.
7. Depress air restriction indicator (A) button and release to reset indicator.

- A—Restriction Indicator
- B—Cover
- C—Filter Element
- D—Dust Unloader Valve
- E—Light-Duty Filter Element
- F—Clamp
- G—Restriction Indicator



Air Cleaner Components (European Sourced)

RG11547 -UN-01DEC00



Light-Duty Air Cleaner


RG14644 -UN-30MAY06

DPSG,OUOD002,1580 -19-30MAY06-2/2

Inspecting Primary Filter Element

Inspect filter to determine if it is practical to clean or for damage after cleaning filter.

1. Hold a bright light (A) inside element and check carefully for holes. Discard any element which shows the smallest hole or rupture.
2. Be sure outer screen (B) is not dented. Vibration would quickly wear a hole in filter.
3. Be sure filter gasket (C) is in good condition. If gasket is damaged or missing, replace element.



Inspecting Primary Air Filter Element

A—Light
B—Outer Screen
C—Gasket

IMPORTANT: Air cleaner MUST BE DRY before storing in plastic bag.

If the filter is to be stored for later use, place it in a plastic bag to protect it from dust and damage.

RG, RG34710, 3598 -19-30AUG96-1/1

Cleaning Primary Filter Element

IMPORTANT: Always replace secondary (safety) filter elements. DO NOT attempt to clean them.

Do not blow air from outside portion of filter with air nozzle. Wear safety glasses and remove bystanders.

1. Gently pat sides of element with palm of hand to loosen dirt. DO NOT tap element against a hard surface.

Continued on next page

RG, RG34710, 3599 -19-30AUG96-1/2

CAUTION: Only a special air cleaning gun (A) should be used. Concentrated air pressure from an ordinary air nozzle may severely damage filter element. Do not exceed 210 kPa (2.1 bar) (30 psi) when cleaning filter element.



Cleaning Primary Element

A—Air Cleaning Gun

2. Insert the cleaning gun into element, hold air nozzle about 25.4 mm (1.0 in.) from perforated metal retainer. Force air through filter from inside to outside and move air gun up and down pleats to remove as much dirt as possible.
3. Repeat steps 1 and 2 to remove additional dirt.
4. Inspect element for damage after cleaning. Replace element if any damage is found.

RG, RG34710, 3599 -19-30AUG96-2/2

Element Storage

IMPORTANT: Air cleaner element MUST BE DRY before storing in plastic bag.

Seal element in a plastic bag and store in shipping container to protect against dust and damage.

RG, RG34710, 3601 -19-30AUG96-1/1

Replace Fan And Alternator Belts

Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary. (See CHECKING FAN AND ALTERNATOR V-BELT TENSION in Lubrication and Maintenance/250 Hour Section.)

RG, RG34710, 5086 -19-30JAN98-1/1

Inspecting Power Take-Off (PTO) Clutch

CAUTION: Entanglement in rotating driveline can cause serious injury or death. Keep shield on PTO drive shaft (A) between the clutch housing and the engine driven equipment at all times during engine operation. Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments.

Proper performance of the power take-off unit will be related to the care it is given. Lubricate it periodically and keep the clutch properly adjusted. (See LUBRICATION AND MAINTENANCE/250 HOUR Section.)


NOTE: For standard 500 rpm PTO operation, run engine at 2400 rpm.

If the power take-off does not work properly after adjustment and lubrication, contact your authorized servicing dealer or engine distributor.

A—PTO Driveshaft



Beware of Rotating Drivelines



PTO Drive Shaft

TS198 -UN-23AUG88

RG4693 -UN-14DEC88

RG, RG34710, 5087 -19-11FEB03-1/1

Checking Fuses

The following instructions apply to engines equipped with a John Deere instrument panel.

On North American Instrument Panels:

1. Check the fuse (A) and replace as necessary with an equivalent 14-amp fuse.



RG11548 -UN-01DEC00

North American Instrument Panel

OUOD013,0000003 -19-28NOV00-1/3


On AEZ Instrument Panels (Except North America):

1. Remove the four cap screws (B) holding the instrument panel board.
2. Open fuse holder (C).
3. Replace as necessary with an equivalent 16-amp fuse (D).

IMPORTANT: Always replace a blown fuse with a fuse of the same amperage.

4. Reinstall the instrument panel board.

- B—Cap Screws
- C—Fuse Holder
- D—16-Amp Fuse



RG8149 -UN-01DEC00


AEZ Instrument Panel (Except North America)

Continued on next page

OUOD013,0000003 -19-28NOV00-2/3

On VDO Instrument Panels (Except North America):

5. The fuse is located on the electronic control card inside the panel's rear access cover. Remove cover and check fuse. If defective, replace with a 10 amp fuse. There is a spare fuse available on the card in the "SPARE" terminal.



VDO Instrument Panel (Except North America)

RG10606A -UN-19JUN00

OUOD013.0000003 -19-28NOV00-3/3

Troubleshooting

General Troubleshooting Information

Troubleshooting engine problems can be difficult. An engine wiring diagram is provided in this section to help isolate electrical problems on power units using John Deere wiring harness and instrument (gauge) panel.

Later in this section is a list of possible engine problems that may be encountered accompanied by possible causes and corrections. The illustrated diagrams and troubleshooting information are of a general nature, final design of the overall system for your engine application may be different. See your engine distributor or servicing dealer if you are in doubt.


A reliable program for troubleshooting engine problems should include the following basic diagnostic thought process:

- Know the engine and all related systems.
- Study the problem thoroughly.
- Relate the symptoms to your knowledge of engine and systems.
- Diagnose the problem starting with the easiest things first.
- Double-check before beginning the disassembly.
- Determine cause and make a thorough repair.
- After making repairs, operate the engine under normal conditions to verify that the problem and cause were corrected.

RG, RG34710, 5089 -19-30JAN98-1/1

North American Wiring Diagram

| S1 KEY SWITCH | | | | | |
|---------------|---|---|------|----|-----|
| | B | G | ACC. | ON | ST. |
| OFF | | | | | |
| ACC. | • | | • | | |
| ON | • | | • | • | |
| START | • | • | | • | • |



North American Wiring Diagram

Continued on next page

RG, RG34710, 5091 -19-30JAN98-1/2

Troubleshooting

| | | | |
|---|--|---|---------------------------|
| A1—Speed Control Unit | H2—Oil Pressure Indicator Lamp | P6—Ammeter | Y2—Fuel Shut-Off Solenoid |
| B1—Magnetic Speed Sensor | K1—Starter Relay | R1—Resistor (48 ohm) | BLK—Black |
| B2—Coolant Temperature Sensor | M1—Starter Motor | S1—Key Switch | BLU—Blue |
| B3—Oil Pressure Sensor | P1—Coolant Temperature Gauge | S2—Magnetic Safety Switch— North American , Auto Override Module— European (Saran) | BRN—Brown |
| F1—Starting Circuit Fuse (14 Amp) | P2—Oil Pressure Gauge | W1—Ground on K1 Starter Relay Mounting Stud | DK BLU—Dark Blue |
| F3—Fuse (Early Models) ¹ | P3—Crankcase Oil Level Switch/Gauge | Y1—Starter Solenoid | GRN—Green |
| G1—Battery | P4—Tachometer ¹ | | ORG—Orange |
| G2—Alternator | P5—Hourmeter ² | | PUR—Purple |
| H1—Coolant Temperature Indicator Light | | | RED—Red |
| | | | YEL—Yellow |

¹P4 tachometer has a built-in hourmeter. On some earlier engines, a separate hourmeter (P5) and fuse (F3) are used.

²P4 tachometer has a built-in hourmeter. On some engines, a separate hourmeter (P5) and fuse (F3) are used.

RG, RG34710, 5091 -19-30JAN98-2/2

Engine Troubleshooting

| Symptom | Problem | Solution |
|---|--|---|
| Engine Will Not Crank | Weak battery | Replace battery. |
| | Corroded or loose battery connections | Clean battery terminals and connections. |
| | Defective main switch or start safety switch | Repair switch as required. |
| | Starter solenoid defective | Replace solenoid. |
| | Starter defective | Replace starter. |
| Engine cranks but will not start | Incorrect starting procedure. | Verify correct starting procedure. |
| | No fuel. | Check fuel in tank and manual shut-off valve. |
| | Exhaust restricted. | Check and correct exhaust restriction. |
| | Fuel filter plugged or full of water. | Replace fuel filter or drain water from filter. |
| | Injection pump not getting fuel or air in fuel system. | Check fuel flow at supply pump or bleed fuel system. |
| | Faulty injection pump or nozzles. | Consult authorized diesel repair station for repair or replacement. |

Continued on next page

RG, RG34710, 5092 -19-30JAN98-1/8

| Symptom | Problem | Solution |
|---|-------------------------------------|---|
| Engine hard to start or will not start | Engine starting under load. | Disengage PTO. |
| | Improper starting procedure. | Review starting procedure. |
| | No fuel. | Check fuel tank. |
| | Air in fuel line. | Bleed fuel line. |
| | Cold weather. | Use cold weather starting aids. |
| | Slow starter speed. | See "Starter Cranks Slowly". |
| | Crankcase oil too heavy. | Use oil of proper viscosity. |
| | Improper type of fuel. | Consult fuel supplier; use proper type fuel for operating conditions. |
| | Water, dirt, or air in fuel system. | Drain, flush, fill, and bleed system. |
| | Clogged fuel filter. | Replace filter element. |
| | Dirty or faulty injection nozzles. | Have authorized servicing dealer or engine distributor check injectors. |
| | Injection pump shut-off not reset. | Turn key switch to "OFF" then to "ON". |
| | Poor fuel quality | Drain fuel and replace with quality fuel of the proper grade. |
| | Slow cranking speed | Check for problem in the charging/starting system. |
| Engine knocks | Low engine oil level. | Add oil to engine crankcase. |
| | Injection pump out of time. | See your authorized servicing dealer or engine distributor. |
| | Low coolant temperature. | Remove and check thermostat. |
| | Engine overheating. | See "Engine Overheats". |

Continued on next page

RG, RG34710, 5092 -19-30JAN98-2/8

Troubleshooting

| Symptom | Problem | Solution |
|---|--|---|
| Engine runs irregularly or stalls frequently | Low coolant temperature. | Remove and check thermostat. |
| | Clogged fuel filter. | Replace fuel filter element. |
| | Water, dirt, or air in fuel system. | Drain, flush, fill, and bleed system. |
| | Dirty or faulty injection nozzles. | Have authorized servicing dealer or engine distributor check injectors. |
| Below normal engine temperature | Defective thermostat. | Remove and check thermostat. |
| | Defective temperature gauge or sender. | Check gauge, sender, and connections. |

Continued on next page

RG, RG34710, 5092 -19-30JAN98-3/8

| Symptom | Problem | Solution |
|----------------------------|---|---|
| Lack of power | Engine overloaded. | Reduce load. |
| | Intake air restriction. | Service air cleaner. |
| | Clogged fuel filter. | Replace filter elements. |
| | Improper type of fuel. | Use proper fuel. |
| | Poor fuel quality | Drain fuel and replace with quality fuel of the proper grade. |
| | Overheated engine. | See "Engine Overheats". |
| | Below normal engine temperature. | Remove and check thermostat. |
| | Improper valve clearance. | See your authorized servicing dealer or engine distributor. |
| | Dirty or faulty injection nozzles. | Have authorized servicing dealer or engine distributor check injectors. |
| | Injection pump out of time. | See your authorized servicing dealer or engine distributor. |
| | Turbocharger not functioning. (Turbocharged engines only.) | See your authorized servicing dealer or engine distributor. |
| | Leaking exhaust manifold gasket. | See your authorized servicing dealer or engine distributor. |
| | Defective aneroid control line. | See your authorized servicing dealer or engine distributor. |
| | Restricted fuel hose. | Clean or replace fuel hose. |
| Low fast idle speed. | See your authorized servicing dealer or engine distributor. | |
| Engine idles poorly | Poor fuel quality | Drain fuel and replace with quality fuel of the proper grade. |
| | Engine out of time | See your authorized servicing dealer or engine distributor. |
| | Air leak on suction side of air intake system. | Check hose and pipe connections for tightness; repair as required. |

Continued on next page

RG, RG34710, 5092 -19-30JAN98-4/8

| Symptom | Problem | Solution |
|---|--|--|
| Low oil pressure | Low oil level. | Add oil. |
| | Improper type of oil. | Drain, fill crankcase with oil of proper viscosity and quality. |
| High oil consumption | Crankcase oil too light. | Use proper viscosity oil. |
| | Oil leaks. | Check for leaks in lines, gaskets, and drain plug. |
| | Restricted crankcase vent tube. | Clean vent tube. |
| | Defective turbocharger. | See your authorized servicing dealer or engine distributor. |
| Engine emits white exhaust smoke | Improper type of fuel. | Use proper fuel. |
| | Low engine temperature. | Warm up engine to normal operating temperature. |
| | Defective thermostat. | Remove and check thermostat. |
| | Defective injection nozzles. | See your authorized servicing dealer or engine distributor. |
| | Engine out of time (retarded). | See your authorized servicing dealer or engine distributor. |
| | Coolant entering combustion chamber (failed cylinder head gasket or cracked cylinder head) | Repair or replace as required. See your John Deere engine distributor or servicing dealer. |
| | Engine compression too low | Determine cause of low compression and repair as required. See your John Deere engine distributor or servicing dealer. |

Continued on next page

RG, RG34710, 5092 -19-30JAN98-5/8

| Symptom | Problem | Solution |
|---|--|---|
| Engine emits black or gray exhaust smoke | Improper type of fuel. | Use proper fuel. |
| | Clogged or dirty air cleaner. | Service air cleaner. |
| | Engine overloaded. | Reduce load. |
| | Injection nozzles dirty. | See your authorized servicing dealer or engine distributor. |
| | Engine out of time. | See your authorized servicing dealer or engine distributor. |
| | Turbocharger not functioning. | See your authorized servicing dealer or engine distributor. |
| | Engine burning oil | See LUBRICATION SYSTEM TROUBLESHOOTING, later in this section. |
| | Defective muffler/exhaust piping (causing back-pressure) | Replace muffler or defective piping. |
| Engine Overheats | Engine overloaded. | Reduce load. |
| | Low coolant level. | Fill radiator to proper level, check radiator and hoses for loose connections or leaks. |
| | Faulty radiator cap. | Have technician check. |
| | Loose or defective fan belts. | Adjust belt tension. Replace as required. |
| | Low engine oil level. | Check oil level. Add oil as required. |
| | Cooling system needs flushing. | Flush cooling system. |
| | Defective thermostat. | Remove and check thermostat. |
| | Defective temperature gauge or sender. | Check coolant temperature with thermometer and replace, if necessary. |
| | Incorrect grade of fuel. | Use correct grade of fuel. |

Continued on next page

RG, RG34710, 5092 -19-30JAN98-6/8

| Symptom | Problem | Solution |
|------------------------------|-------------------------------|--|
| High fuel consumption | Improper type of fuel. | Use proper type of fuel. |
| | Clogged or dirty air cleaner. | Service air cleaner. |
| | Engine overloaded. | Reduce load. |
| | Improper valve clearance. | See your authorized servicing dealer or engine distributor. |
| | Injection nozzles dirty. | See your authorized servicing dealer or engine distributor. |
| | Engine out of time. | See your authorized servicing dealer or engine distributor. |
| | Defective turbocharger. | See your authorized servicing dealer or engine distributor. |
| | Low engine temperature. | Check thermostat. |
| Fuel in Oil | Compression too low. | Determine cause of low compression and repair as needed. |
| | Cracked cylinder head | Locate crack, repair/replace components as required. See your John Deere engine distributor or servicing dealer. |

Continued on next page

RG, RG34710, 5092 -19-30JAN98-7/8

| Symptom | Problem | Solution |
|------------------------------|--|---|
| Abnormal Engine Noise | Worn main or connecting rod bearings | Determine bearing clearance. See your John Deere engine distributor or servicing dealer. |
| | Excessive crankshaft end play | Check crankshaft end play. See your John Deere engine distributor or servicing dealer. |
| | Loose main bearing caps | Check bearing clearance; replace bearings and bearing cap screws as required. See your John Deere engine distributor or servicing dealer. |
| | Worn connecting rod bushings and piston pins | Inspect piston pins and bushings. See your John Deere engine distributor or servicing dealer. |
| | Scored pistons | Inspect pistons. See your John Deere engine distributor or servicing dealer. |
| | Worn timing gears or excess backlash | Check timing gear back lash. See your John Deere engine distributor or servicing dealer. |
| | Excessive valve clearance | Check and adjust valve clearance. See your John Deere engine distributor or servicing dealer. |
| | Worn camshaft lobes | Inspect camshaft. See your John Deere engine distributor or servicing dealer. |
| | Worn rocker arm shaft(s) | Inspect rocker arm shafts. See your John Deere engine distributor or servicing dealer. |
| | Insufficient engine lubrication | See LUBRICATION SYSTEM TROUBLESHOOTING, later in this section. |
| | Turbocharger noise | See AIR INTAKE SYSTEM TROUBLESHOOTING, later in this section. |

Electrical Troubleshooting

| Symptom | Problem | Solution |
|------------------------------------|---|---|
| Undercharged system | Excessive electrical load from added accessories. | Remove accessories or install higher output alternator. |
| | Excessive engine idling. | Increase engine rpm when heavy electrical load is used. |
| | Poor electrical connections on battery, ground strap, starter, or alternator. | Inspect, clean and tighten as necessary. |
| | Defective battery. | Test battery. |
| | Defective alternator. | Test charging system. |
| Battery used too much water | Cracked battery case. | Check for moisture and replace as necessary. |
| | Defective battery. | Test battery. |
| | Battery charging rate too high. | Test charging system. |
| Batteries will not charge | Loose or corroded connections. | Clean and tighten connections. |
| | Sulfated or worn-out batteries. | See your authorized servicing dealer or engine distributor. |
| | Loose or defective alternator belt. | Adjust belt tension or replace belts. |
| Starter will not crank | PTO engaged. | Disengage PTO. |
| | Loose or corroded connections. | Clean and tighten loose connections. |
| | Low battery output voltage. | See your authorized servicing dealer or engine distributor. |
| | Faulty start circuit relay. | See your authorized servicing dealer or engine distributor. |
| | Blown fuse. | Replace fuse. |

Continued on next page

RG, RG34710, 5093 -19-30JAN98-1/2

Troubleshooting

| Symptom | Problem | Solution |
|---|---------------------------------|---|
| Starter cranks slowly | Low battery output. | See your authorized servicing dealer or engine distributor. |
| | Crankcase oil too heavy. | Use proper viscosity oil. |
| | Loose or corroded connections. | Clean and tighten loose connections. |
| Entire electrical system does not function | Faulty battery connection. | Clean and tighten connections. |
| | Sulfated or worn-out batteries. | See your authorized servicing dealer or engine distributor. |
| | Blown fuse. | Replace fuse. |

RG, RG34710, 5093 -19-30JAN98-2/2

Lubrication System Troubleshooting

| Symptom | Problem | Solution |
|--------------------------|--|---|
| Low Oil Pressure | Low crankcase oil level | Fill crankcase to proper oil level. |
| | Clogged oil cooler or filter | Remove and inspect oil cooler. See your John Deere engine distributor or servicing dealer. |
| | Excessive oil temperature | Remove and inspect oil cooler. See your John Deere engine distributor or servicing dealer. |
| | Defective oil pump | Remove and inspect oil pump. See your John Deere engine distributor or servicing dealer. |
| | Incorrect oil | Drain crankcase and refill with correct oil. |
| | Oil pressure regulating valve failure | Remove and inspect oil pressure regulating valve. See your John Deere engine distributor or servicing dealer. |
| | Clogged oil pump screen or cracked pick-up tube | Remove oil pan and clean screen/replace pick-up tube. |
| High Oil Pressure | Excessive main or connecting rod bearing clearance | Determine bearing clearance. See your John Deere engine distributor or servicing dealer. |
| | Improper oil classification | Drain crankcase and refill with correct oil. |
| | Oil pressure regulating valve failure | Remove and inspect oil pressure regulating valve. See your John Deere engine distributor or servicing dealer. |
| | Stuck or damaged filter bypass valve | Remove and inspect filter bypass valve. See your John Deere engine distributor or servicing dealer. |
| | Stuck or damaged oil cooler bypass valve | Remove and inspect oil cooler bypass valve. See your John Deere engine distributor or servicing dealer. |

Continued on next page

RG, RG34710, 7600 -19-30JUN97-1/3

| Symptom | Problem | Solution |
|----------------------------------|--|---|
| Excessive Oil Consumption | Too low viscosity crankcase oil | Drain crankcase and refill with correct viscosity oil. |
| | Crankcase oil level too high | Drain oil until oil level is correct. |
| | External oil leak(s) | Determine source of oil leak(s) and repair as required. |
| | Oil control rings worn or broken | Replace piston rings. See your John Deere engine distributor or servicing dealer. |
| | Scored cylinder liners or pistons | Remove and inspect cylinders and liners; replace as required. See your John Deere engine distributor or servicing dealer. |
| | Worn valve guides or stems | Inspect and measure valve stems and valve guides; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Excessive oil pressure | See High Oil Pressure. |
| | Piston ring grooves excessively worn | Remove and inspect pistons. See your John Deere engine distributor or servicing dealer. |
| | Piston rings sticking in ring grooves | Remove and inspect pistons. See your John Deere engine distributor or servicing dealer. |
| | Insufficient piston ring tension | Remove and inspect pistons. See your John Deere engine distributor or servicing dealer. |
| | Piston ring gaps not staggered | Remove and inspect pistons. See your John Deere engine distributor or servicing dealer. |
| | Front and/or rear crankshaft oil seal faulty | Replace oil seals. See your John Deere engine distributor or servicing dealer. |

Continued on next page

RG, RG34710, 7600 -19-30JUN97-2/3

| Symptom | Problem | Solution |
|-----------------------|---------|--|
| | | See LOW PRESSURE SYSTEM-FUEL PRESSURE LOW TROUBLESHOOTING earlier in this section. |
| Fuel in Oil | | See FUEL IN OIL TROUBLESHOOTING earlier in this section. |
| Coolant in Oil | | See COOLING SYSTEM TROUBLESHOOTING later in this section. |

RG, RG34710, 7600 -19-30JUN97-3/3

Cooling System Troubleshooting

| Symptom | Problem | Solution |
|-------------------------|-----------------------------------|--|
| Engine Overheats | Lack of coolant in cooling system | Fill cooling system to proper level. |
| | Radiator core dirty | Clean radiator as required. |
| | Engine overloaded | Reduce engine load. |
| | Too low crankcase oil level | Fill crankcase to proper oil level. |
| | Loose or defective fan belt | Replace fan belt as required. Check belt tensioner. (See Lubrication and Maintenance 500 Hour/12 Month Section.) |
| | Defective thermostat | Test thermostat opening temperature; replace thermostat as required. |
| | Damaged cylinder head gasket | Replace cylinder head gasket. See your John Deere engine distributor or servicing dealer. |
| | Defective coolant pump | Replace coolant pump. See your John Deere engine distributor or servicing dealer. |
| | Defective radiator cap | Replace radiator cap as required. |

Continued on next page

RG, RG34710, 7601 -19-11FEB03-1/2

| Symptom | Problem | Solution |
|---|--|---|
| Coolant in Oil | Cylinder head gasket defective | Replace cylinder head gasket. See your John Deere engine distributor or servicing dealer. |
| | Cylinder head or block cracked | Locate crack, repair/replace components as required. |
| | Cylinder liner seals leaking | Remove and inspect cylinder liners. See your John Deere engine distributor or servicing dealer. |
| | Leaking oil cooler | Pressure test oil cooler; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| | Defective oil cooler O-rings | Remove and inspect oil cooler O-rings; replace as required. See your John Deere engine distributor or servicing dealer. |
| | Faulty coolant pump seal; weep hole plugged; coolant leaking through bearing | Replace coolant pump seals. See your John Deere engine distributor or servicing dealer. |
| Coolant Temperature Below Normal | Defective thermostat(s) | Test thermostats; replace thermostats as required. |

RG, RG34710, 7601 -19-11FEB03-2/2

Air Intake System Troubleshooting

If turbocharger requires replacement, determine what caused the failure of the defective unit, and correct the condition. This will prevent an immediate repeat failure of the replacement unit.

NOTE: Turbochargers are equipped on 3029T engines only.

| Symptom | Problem | Solution |
|---|--|--|
| Hard to Start or Will Not Start | | See ENGINE TROUBLESHOOTING earlier in this section. |
| Engine Misfiring or Runs Irregularly | | See ENGINE TROUBLESHOOTING earlier in this section. |
| Black or Grey Exhaust Smoke | | See ENGINE TROUBLESHOOTING earlier in this section. |
| Lack of Engine Power | | See ENGINE TROUBLESHOOTING earlier in this section. |
| Turbocharger "Screams" | Air leak in intake manifold. | Check intake manifold gasket and manifold; repair as required. See your John Deere engine distributor or servicing dealer. |
| Turbocharger Noise or Vibration <i>NOTE: Do not confuse the whine heard during run down with noise which indicates a bearing failure.</i> | Bearings not lubricated (insufficient oil pressure) | Determine cause of lack of lubrication; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Air leak in engine intake or exhaust manifold | Check intake and exhaust manifold gaskets and manifolds; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Improper clearance between turbine wheel and turbine housing | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| | Broken blades (or other wheel failures) | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |

| Symptom | Problem | Solution |
|--|--|--|
| Oil on Turbocharger Compressor Wheel or in Compressor Housing (Oil Being Pushed or Pulled Through Center Housing) | Excessive crankcase pressure. | Determine cause of excessive crankcase pressure; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Air intake restriction | Determine cause of intake restriction; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Drain tube restriction | Determine cause of drain tube restriction; repair as required. See your John Deere engine distributor or servicing dealer. |
| Oil in Intake Manifold or Dripping from Turbocharger Housing | Excessive crankcase pressure | Determine cause of excessive crankcase pressure; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Air intake restriction | Determine cause of intake restriction; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Drain tube restriction | Determine cause of drain tube restriction; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Damaged or worn housing bearings | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| | Imbalance of rotating assembly | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| | Damage to turbine or compressor wheel or blade | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| | Dirt or carbon build-up on wheel or blade | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |

Continued on next page

RG, RG34710, 7602 -19-13MAR03-2/3

| Symptom | Problem | Solution |
|--|---|---|
| | Bearing wear | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| | Oil starvation or insufficient lubrication | Determine cause of lack of lubrication; repair as required. See your John Deere engine distributor or servicing dealer. |
| | Shaft seals worn | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| Turbocharger Turbine Wheel Drag | Carbon build-up behind turbine wheel caused by coked oil or combustion deposits | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| | Dirt build-up behind compressor wheel caused by air intake leaks. | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| | Bearing seizure or dirty, worn bearings | Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer. |
| Turbocharger Wastegate Mechanism (If Equipped) Does Not Operate | Pivot shaft or rod linkage seized | Inspect wastegate mechanism. If required, see your John Deere engine distributor or servicing dealer. |

RG, RG34710, 7602 -19-13MAR03-3/3

Storage

Engine Storage Guidelines

1. John Deere engines can be stored outside for up to three (3) months with no long term preparation IF COVERED BY WATERPROOF COVERING. No outside storage is recommended without a waterproof covering.
2. John Deere engines can be stored in a standard overseas shipping container for up to three (3) months with no long term preparation.
3. John Deere engines can be stored inside for up to six (6) months with no long term preparation.
4. John Deere engines expected to be stored more than six (6) months MUST have long term storage preparation. (See PREPARING ENGINE FOR LONG TERM STORAGE, later in this section.)
5. Long term storage includes the use of a stabilized rust preventive oil to protect internal metal components of the engine. This oil should be an SAE 10 oil with 1-4 percent morpholine or equivalent vapor corrosion inhibitor. These rust preventive oils are available from area distributors.

OURGP12,00000DF -19-07JAN05-1/1

Preparing Engine for Long Term Storage

The following storage preparations are used for long term engine storage up to one year. After that, the engine should be started, warmed up, and retreated for an extended storage period.

IMPORTANT: Any time your engine will not be used for over six (6) months, the following recommendations for storing it and removing it from storage will help to minimize corrosion and deterioration.

1. Change engine oil and replace filter. (For all except 3029TF270 engines, see CHANGE ENGINE OIL AND FILTER in Lubrication and Maintenance/250 Hour/6 Month Section. For 3029TF270 engines, see the 500 Hour/12 Month section.) Used oil will not give adequate protection. Add one (1) ounce of rust preventive oil to the engine crankcase for every quart of oil. This rust preventive oil should be an SAE 10 oil with 1-4 percent morpholine or equivalent vapor corrosion inhibitor.
 2. Service air cleaner. (See REPLACING AIR CLEANER FILTER ELEMENTS in Service As Required Section.)
 3. Draining and flushing of cooling system is not necessary if engine is to be stored only for several months. However, for extended storage periods of a year or longer, it is recommended that the cooling system be drained, flushed, and refilled. Refill with appropriate coolant. (See RECOMMENDED ENGINE COOLANT in Fuels, Lubricants, and Coolant Section and ADDING COOLANT in Service As Required Section.)
 4. Pour three (3) ounces of rust preventive oil into the turbocharger intake. (It may be necessary to temporarily install a short intake elbow on the turbocharger inlet to receive the oil.)
 5. Prepare a tank with a solution of diesel fuel and rust preventive oil, at ten (10) ounces of rust preventive oil per gallon of diesel fuel.
 6. Remove existing lines/plugs as required, and run a temporary line from the tank to the engine fuel intake, and another temporary line from the fuel return manifold to the tank, so rust preventive oil solution is circulated through the injection system during cranking.
 7. Crank the engine several revolutions with starter (do not allow the engine to start). This will allow rust preventive oil solution to circulate.
 8. Remove temporary lines installed in Step 6 above, and replace any lines/plugs previously removed.
- NOTE: One gallon of fuel/oil solution can be used to treat 100 engines; two gallons to treat 200 engines, etc. The oil could then be replenished by adding an additional five (5) ounces of rust preventive oil per gallon of solution. However, starting over with a new solution is recommended to dispose of any water or other impurities.*
9. Loosen, or remove and store, fan/alternator poly-vee belt.
 10. Remove and clean batteries. Store them in a cool, dry place and keep them fully charged.
 11. Disengage the clutch for any driveline.
 12. Clean the exterior of the engine with salt-free water and touch up any scratched or chipped painted surfaces with a good quality paint.
 13. Coat all exposed (machined) metal surfaces with grease or corrosion inhibitor if not feasible to paint.
 14. Seal all openings on engine with plastic bags and tape.
 15. Store the engine in a dry protected place. If engine must be stored outside, cover it with a waterproof canvas or other suitable protective material and use a strong waterproof tape.

Removing Engine from Long Term Storage

Refer to the appropriate section for detailed services listed below or have your authorized servicing dealer or engine distributor perform services that you may not be familiar with.

1. Remove all protective coverings from engine. Unseal all openings in engine and remove covering from electrical systems.
2. Remove the batteries from storage. Install batteries (fully charged) and connect the terminals.
3. Install fan/alternator poly-vee belt if removed.
4. Fill fuel tank.
5. Perform all appropriate prestarting checks. (See DAILY PRESTARTING CHECKS in Lubrication and Maintenance/Daily Section.)

IMPORTANT: DO NOT operate starter more than 30 seconds at a time. Wait at least 2 minutes for starter to cool before trying again.

6. Crank engine for 20 seconds with starter (do not allow the engine to start). Wait 2 minutes and crank engine an additional 20 seconds to assure bearing surfaces are adequately lubricated.
7. Start engine and run at low idle and no load for several minutes. Warm up carefully and check all gauges before placing engine under load.
8. On the first day of operation after storage, check overall engine for leaks and check all gauges for correct operation.

RG, RG34710, 5613 -19-20MAY96-1/1

Specifications

General OEM Engine Specifications

| ITEM | 3029DF120 | 3029DF150 | 3029DF160 | 3029DF180 | 3029TF120 | 3029TF150 | 3029TF160 | 3029TF180/ 3029TF270 |
|----------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|-------------------------|
| Number of Cylinders | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Fuel | Diesel | Diesel | Diesel | Diesel | Diesel | Diesel | Diesel | Diesel |
| Bore | 106.5 mm (4.19 in.) | 106.5 mm (4.19 in.) | 106.5 mm (4.19 in.) | 106.5 mm (4.19 in.) | 106.5 mm (4.19 in.) | 106.5 mm (4.19 in.) | 106.5 mm (4.19 in.) | 106.5 mm (4.19 in.) |
| Stroke | 110 mm (4.33 in.) | 110 mm (4.33 in.) | 110 mm (4.33 in.) | 110 mm (4.33 in.) | 110 mm (4.33 in.) | 110 mm (4.33 in.) | 110 mm (4.33 in.) | 110 mm (4.33 in.) |
| Displacement | 2.9 L (179 cu in.) | 2.9 L (179 cu in.) | 2.9 L (179 cu in.) | 2.9 L (179 cu in.) | 2.9 L (179 cu in.) | 2.9 L (179 cu in.) | 2.9 L (179 cu in.) | 2.9 L (179 cu in.) |
| Compression Ratio | 17.8:1 | 17.8:1 | 17.8:1 | 17.8:1 | 17.8:1 | 17.8:1 | 17.8:1 | 17.8:1/17.2:1 |
| Physical Dimensions: | | | | | | | | |
| Width | 519 mm (20.4 in.) | 519 mm (20.4 in.) | 528 mm (20.8 in.) | 528 mm (20.8 in.) | 519 mm (20.4 in.) | 519 mm (20.4 in.) | 528 mm (20.8 in.) | 528 mm (20.8 in.) |
| Height | 819 mm (32.2 in.) | 819 mm (32.2 in.) | 819 mm (32.2 in.) | 819 mm (32.2 in.) | 928 mm (36.5 in.) | 928 mm (36.5 in.) | 928 mm (36.5 in.) | 928 mm (36.5 in.) |
| Length | 716 mm (28.2 in.) | 716 mm (28.2 in.) | 716 mm (28.2 in.) | 716 mm (28.2 in.) | 716 mm (28.2 in.) | 716 mm (28.2 in.) | 716 mm (28.2 in.) | 716 mm (28.2 in.) |
| Basic Dry Weight | 316 kg (696 lb) | 316 kg (696 lb) | 317 kg (698 lb) | 317 kg (698 lb) | 328 kg (722 lb) | 328 kg (722 lb) | 329 kg (724 lb) | 329 kg (724 lb) |

Continued on next page

RG, RG34710, 5098 -19-31MAY06-1/2

NOTE: Engine models listed above with numbers ending in "120" and "160" are emission non-certified. Engines with model numbers ending in "150" and "180" are Tier I emission certified, as explained later in this manual. Engines with model numbers ending in "270" are Tier II emission certified.

NOTE: Effective in April 2005, engine serial numbers were changed at the 7th digit to show the Emission Level. Previously this digit identified the type of aspiration.

On earlier engines the 7th digit showed the aspiration code as follows:

- "A" for turbocharged with air-to-water aftercooler
- "D" for naturally aspirated
- "H" for turbocharged with air-to-air aftercooler
- "T" for turbocharged only

On later engines after April 2005, the seventh digit will be as follows:

- "B" for non-certified engines
- "C" for Tier 1 / Stage I engines
- "G" for Tier 2 / Stage II engines
- "L" for Tier 3 / Stage IIIA engines

Engine Power and Speed Specifications¹—Tier I Emission Certified Engines

| ENGINE MODEL | OPTION CODES | FUEL INJECTION PUMP PART NUMBER | POWER RATING @ RATED SPEED ^a kW (hp) | RATED SPEED ^b (rpm) | SLOW IDLE (rpm) | FAST IDLE ^c (rpm) |
|--------------|--------------|---------------------------------|---|--------------------------------|-----------------|------------------------------|
| CD3029DF150 | 16DP | RE502217 | 43 (58) | 2500 | 850 | 2700 |
| | 16EG | RE501983 | 43 (58) | 2500 | 850 | 2700 |
| | 16EQ | RE502509 | 43 (58) | 2500 | 1700 | 2700 |
| | 16HW | RE501259 | 36 (48) | 2500 | 850 | 2700 |
| | 16PN | RE502217 | 43 (58) | 2500 | 850 | 2700 |
| CD3029DF151 | 16DZ | RE501258 | 43 (58) | 2500 | 850 | 2700 |
| CD3029DF152 | 16KZ | RE502217 | 43 (58) | 2500 | 850 | 2700 |
| CD3029DF180 | 16DR | RE502217 | 43 (58) | 2500 | 850 | 2700 |
| | 16EH | RE501983 | 43 (58) | 2500 | 850 | 2700 |
| | 16NP | RE502217 | 43 (58) | 2500 | 850 | 2700 |
| CD3029TF150 | 16DE | RE502218 | 59 (79) | 2500 | 850 | 2700 |
| | 16DF | RE502238 | 52 (70) | 2500 | 850 | 2700 |
| | 16EJ | RE501985 | 59 (79) | 2500 | 850 | 2700 |
| | 16EK | RE502986 | 52 (70) | 2500 | 850 | 2700 |
| | 16TR | RE506877 | 48 (64) | 1800 | — | 1890 |
| | 16TS | RE506878 | 48 (64) | 1800 | — | 1890 |
| CD3029TF152 | 16EA | RE501218 | 59 (79) | 2500 | 850 | 2700 |
| CD3029TF180 | 16DG | RE502218 | 59 (79) | 2500 | 850 | 2700 |
| | 16DH | RE502238 | 52 (70) | 2500 | 850 | 2700 |
| | 16EL | RE501985 | 59 (79) | 2500 | 850 | 2700 |
| | 16EM | RE501986 | 52 (70) | 2500 | 850 | 2700 |
| | 16ZB | RE502238 | 52 (70) | 2500 | 850 | 2700 |
| PE3029DF150 | 16DP | RE502217 | 43 (58) | 2500 | 850 | 2700 |
| | 16EG | RE501983 | 43 (58) | 2500 | 850 | 2700 |
| | 16EQ | RE502182 | 43 (58) | 2500 | 850 | 2700 |
| | 16HW | RE501259 | 36 (49) | 2500 | 850 | 2700 |
| | 16PH | RE501259 | 36 (49) | 2500 | 850 | 2700 |
| PE3029TF150 | 16DE | RE502218 | 59 (79) | 2500 | 850 | 2700 |
| | 16DF | RE502238 | 52 (69) | 2500 | 850 | 2700 |
| | 16EJ | RE501985 | 59 (79) | 2500 | 850 | 2700 |
| | 16EK | RE502986 | 52 (69) | 2500 | 850 | 2700 |
| | 16TR | RE506877 | 48 (64) | 1800 | — | 1890 |

^aPower ratings are for a bare engine without the drag effect of accessories like fans, transmission, and auxiliary drives.

^bGenerator set engines (3-5% governor) usually run at 1500 rpm (50 Hz) or 1800 (60 Hz) when operating under load depending on cycles of AC current.

^cFast idle is 7-10% above rated speed for engines with standard governor, and 3-5% above rated speed for generator set governor.

¹Engine speeds listed are preset to factory specification. Slow idle speed may be reset depending upon specific vehicle application requirements. Refer to your machine operator's manual for engine speeds that are different from those preset at the factory.

Specifications

| ENGINE MODEL | OPTION CODES | FUEL INJECTION PUMP PART NUMBER | POWER RATING @RATED SPEED ^a kW (hp) | RATED SPEED ^b (rpm) | SLOW IDLE (rpm) | FAST IDLE ^c (rpm) |
|--------------|--------------|---------------------------------|--|--------------------------------|-----------------|------------------------------|
| | 16TS | RE506878 | 48 (64) | 1800 | | 1890 |

^aPower ratings are for a bare engine without the drag effect of accessories like fans, transmission, and auxiliary drives.

^bGenerator set engines (3-5% governor) usually run at 1500 rpm (50 Hz) or 1800 (60 Hz) when operating under load depending on cycles of AC current.

^cFast idle is 7-10% above rated speed for engines with standard governor, and 3-5% above rated speed for generator set governor.

OUOD002,0000029 -19-12FEB03-2/2

Engine Power and Speed Specifications¹—Tier II Emission Certified (“270”) Engines

| ENGINE MODEL | OPTION CODES | FUEL INJECTION PUMP PART NUMBER | POWER RATING @RATED SPEED ^a kW (hp) | RATED SPEED ^b (rpm) | SLOW IDLE (rpm) | FAST IDLE ^c (rpm) |
|--------------------------------|--------------|---------------------------------|--|--------------------------------|-----------------|------------------------------|
| CD3029TF270 (Saran-built) | 164D | RE519011 | 48 (64) | 2500 | 850 | 2700 |
| | 164E | RE519012 | 48 (64) | 2500 | 850 | 2700 |
| | 164F | RE519013 | 53 (71) | 2500 | 850 | 2700 |
| | 164G | RE519014 | 53 (71) | 2500 | 850 | 2700 |
| | 164H | RE519015 | 48 (64) | 1800 | — | 1890 |
| | 164I | RE519016 | 48 (64) | 1800 | — | 1890 |
| PE3029TF270 (Torreon-built) | 164D | RE519011 | 48 (64) | 2500 | 850 | 2700 |
| | 164E | RE519012 | 48 (64) | 2500 | 850 | 2700 |
| | 164F | RE519013 | 53 (71) | 2500 | 850 | 2700 |
| | 164G | RE519014 | 53 (71) | 2500 | 850 | 2700 |
| | 164H | RE519015 | 48 (64) | 1800 | — | 1890 |
| | 164I | RE519016 | 48 (64) | 1800 | — | 1890 |

^aPower ratings are for a bare engine without the drag effect of accessories like fans, transmission, and auxiliary drives.

^bGenerator set engines (3-5% governor) usually run at 1500 rpm (50 Hz) or 1800 (60 Hz) when operating under load depending on cycles of AC current.

^cFor engines with standard governor, fast idle is 7-10% above rated speed. For engines with generator set governors, fast idle is 3-5% above rated speed.

¹Engine speeds listed are preset to factory specification. Slow idle speed may be reset depending upon specific vehicle application requirements. Refer to your machine operator’s manual for engine speeds that are different from those preset at the factory.

OUOD005,00001D2 -19-12FEB03-1/1

Engine Power and Speed Specifications¹—Emission Non-Certified Engines

| ENGINE MODEL | OPTION CODES | FUEL INJECTION PUMP PART NUMBER | POWER RATING @ RATED SPEED ^a kW (hp) | RATED SPEED ^b (rpm) | SLOW IDLE (rpm) | FAST IDLE ^c (rpm) |
|--------------|--------------|---------------------------------|--|-----------------------------------|--------------------|---------------------------------|
| CD3029DF120 | 1602 | RE53785 | 43 (58) | 2500 | 850 | 2700 |
| | 1603 | RE53786 | 35 (47) | 1800 | — | 1890 |
| | 1641 | RE53787 | 31 (41) | 1500 | — | 1560 |
| | 1642 | RE67271 | 43 (58) | 2500 | 850 | 2700 |
| | 1644 | RE41939 | 34 (46) | 1800 | — | 1890 |
| | 1648 | RE64242 | 30 (40) | 1500 | — | 1560 |
| | 1650 | RE41938 | 43 (58) | 2500 | 850 | 2700 |
| | 1655 | RE53785 | 43 (58) | 2500 | 850 | 2700 |
| CD3029DF121 | 1602 | RE53785 | 43 (58) | 2500 | 800 | 2700 |
| | 1650 | RE41938 | 43 (58) | 2500 | 800 | 2700 |
| CD3029DF122 | 1603 | RE53786 | 35 (47) | 1800 | — | 1890 |
| | 1641 | RE53787 | 31 (41) | 1500 | — | 1560 |
| | 1644 | RE41939 | 34 (46) | 1800 | — | 1890 |
| | 1648 | RE64272 | 30 (40) | 1500 | — | 1560 |
| CD3029DF123 | 16BS | RE53785 | 43 (58) | 2500 | 800 | 2700 |
| CD3029DF124 | 1641 | RE53787 | 31 (41) | 1500 | — | 1560 |
| CD3029DF160 | 1602 | RE53785 | 43 (58) | 2500 | 850 | 2700 |
| | 1632 | RE51940 | 37 (50) | 2200 | 850 | 2400 |
| | 1641 | RE64241 | 31 (41) | 1500 | — | 1560 |
| | 1643 | RE67271 | 43 (58) | 2500 | 850 | 2700 |
| | 1650 | RE41938 | 43 (58) | 2500 | 850 | 2700 |
| CD3029DF162 | 16YG | RE51940 | 37 (50) | 2200 | 800 | 2400 |
| CD3029DF163 | 1654 | RE63523 | 41 (55) | 2400 | 800 | 2600 |
| CD3029DF164 | 16DV | RE53785 | 43 (58) | 2500 | 850 | 2700 |
| CD3029DF165 | 16TH | RE53785 | 43 (58) | 2500 | 850 | 2700 |
| CD3029TF120 | 1602 | RE53783 | 59 (79) | 2500 | 800 | 2700 |
| | 1632 | RE58903 | 59 (79) | 2500 | 800 | 2700 |
| | 1640 | RE53958 | 59 (79) | 2500 | 800 | 2700 |
| | 16TT | RE506879 | 42 (57) | 1500 | — | 1560 |
| | 16TU | RE506880 | 42 (57) | 1500 | — | 1560 |

^aPower ratings are for a bare engine without the drag effect of accessories like fans, transmission, and auxiliary drives.

^bGenerator set engines (3-5% governor) usually run at 1500 rpm (50 Hz) or 1800 (60 Hz) when operating under load depending on cycles of AC current.

^cFor engines with standard governor, fast idle is 7-10% above rated speed. For engines with generator set governors, fast idle is 3-5% above rated speed.


¹Engine speeds listed are preset to factory specification. Slow idle speed may be reset depending upon specific vehicle application requirements. Refer to your machine operator's manual for engine speeds that are different from those preset at the factory.

Specifications

| | | | | | | |
|-------------|-------------|----------|----------|---------|------|------|
| CD3029TF121 | 1602 | RE53783 | 59 (79) | 2500 | 800 | 2700 |
| | 1632 | RE58903 | 59 (79) | 2500 | 800 | 2700 |
| | 1640 | RE53958 | 59 (79) | 2500 | 800 | 2700 |
| CD3029TF123 | 16BT | RE53783 | 59 (79) | 2500 | 800 | 2700 |
| CD3029TF160 | 1602 | RE53783 | 59 (79) | 2500 | 800 | 2700 |
| | 1632 | RE58903 | 59 (79) | 2500 | 800 | 2700 |
| | 1633 | RE51979 | 46 (62) | 2200 | 800 | 2400 |
| | 1634 | RE53783 | 59 (79) | 2500 | 800 | 2700 |
| | 1640 | RE53958 | 59 (79) | 2500 | 800 | 2700 |
| CD3029TF161 | 16EV | RE53958 | 59 (79) | 2500 | 800 | 2700 |
| CD3029TF162 | 1633 | RE51979 | 46 (62) | 2200 | 800 | 2700 |
| CD3029TF163 | 1602 | RE53783 | 59 (79) | 2500 | 800 | 2700 |
| PE3029DF120 | 1602 | RE53785 | 43 (58) | 2500 | 850 | 2700 |
| | 1603 | RE53786 | 35 (47) | 1800 | — | 1890 |
| | 1641 | RE64241 | 43 (58) | 2500 | 850 | 2700 |
| | 1642 | RE67271 | 43 (58) | 2500 | 850 | 2700 |
| | 1644 | RE41939 | 35 (47) | 1800 | — | 1890 |
| | 1648 | RE64242 | 31 (41) | 1500 | — | 1560 |
| | 1650 | RE41938 | 43 (58) | 2500 | 850 | 2700 |
| | 1655 | RE53785 | 43 (58) | 2500 | 850 | 2700 |
| | PE3029TF120 | 16TT | RE506879 | 42 (56) | 1500 | — |
| 16TU | | RE506880 | 42 (56) | 1500 | — | 1560 |
| 1602 | | RE53783 | 59 (79) | 2500 | 850 | 2700 |
| 1632 | | RE58903 | 59 (79) | 2500 | 850 | 2700 |
| 1640 | | RE53958 | 59 (79) | 2500 | 850 | 2700 |

OUOD002,000002A -19-30MAY06-2/2

Engine Crankcase Oil Fill Quantities



Option Code Label (3029TF150 Shown)

A—Dipstick Tube Option (used to determine crankcase oil fill quantity)

To determine the option code for the oil fill quantity of your engine, refer to the engine option code label affixed to the rocker arm cover (shown above). The first two digits of the code (40) (see A) identify the dipstick tube group. The last two digits of the code identify the specific dipstick and tube assembly on your engine.

Listed on next page are engine crankcase oil fill quantities:

Continued on next page

RG, RG34710, 5100 -19-18FEB03-1/3

Specifications

| Engine Model | Dipstick Tube Option Code(s) | Crankcase Oil Capacity |
|---------------------|-------------------------------------|-------------------------------|
| CD3029DF120 | 4002, 4003, 4004, 4005, 4024, 40AA | 6.0 L (6.5 qt) |
| | 4006 | 8.0 L (8.5 qt) |
| | 4022 | 7.0 L (7.5 qt) |
| CD3029DF121 | 4004, 4005 | 6.0 L (6.5 qt) |
| CD3029DF122 | 4004 | 6.0 L (6.5 qt) |
| CD3029DF123 | 4004 | 6.0 L (6.5 qt) |
| CD3029DF124 | 4004 | 6.0 L (6.5 qt) |
| CD3029DF150 | 4004, 4005, 4024 | 6.0 L (6.5 qt) |
| | 4006 | 8.0 L (8.5 qt) |
| | 4022 | 7.0 L (7.5 qt) |
| CD3029DF151 | 4004 | 6.0 L (6.5 qt) |
| CD3029DF152 | 4004 | 6.0 L (6.5 qt) |
| CD3029DF160 | 4024 | 6.0 L (6.5 qt) |
| | 4022 | 7.0 L (7.5 qt) |
| | 4033 | 8.0 L (8.5 qt) |
| CD3029DF161 | 4024 | 6.0 L (6.5 qt) |
| CD3029DF162 | 4006 | 8.0 L (8.5 qt) |
| CD3029DF163 | 4024 | 6.0 L (6.5 qt) |
| CD3029DF164 | 4033 | 8.0 L (8.5 qt) |
| CD3029DF165 | 4024 | 6.0 L (6.5 qt) |
| CD3029DF180 | 4022, 4024 | 7.0 L (7.5 qt) |
| | 4033 | 8.0 L (8.5 qt) |
| CD3029TF120 | 4006, 4025 | 8.0 L (8.5 qt) |
| | 4023 | 9.0 L (9.5 qt) |
| | 4024 | 6.0 L (6.5 qt) |
| CD3029TF121 | 4006, 4024 | 8.0 L (8.5 qt) |
| CD3029TF123 | 4006 | 8.0 L (8.5 qt) |
| CD3029TF150 | 4006, 4025 | 8.0 L (8.5 qt) |
| | 4023 | 9.0 L (9.5 qt) |
| | 4024 | 6.0 L (6.5 qt) |
| CD3029TF152 | 4006 | 8.0 L (8.5 qt) |
| CD3029TF160 | 4023 | 9.0 L (9.5 qt) |
| | 4024 | 6.0 L (6.5 qt) |
| | 4026 | 8.5 L (9.0 qt) |
| | 4033 | 8.0 L (8.5 qt) |
| CD3029TF161 | 4024 | 6.0 L (6.5 qt) |

Continued on next page

RG, RG34710, 5100 -19-18FEB03-2/3

Specifications

| Engine Model | Dipstick Tube Option Code(s) | Crankcase Oil Capacity |
|---------------------|-------------------------------------|-------------------------------|
| CD3029TF162 | 4006 | 8.0 L (8.5 qt) |
| | 4026 | 8.5 L (9.0 qt) |
| CD3029TF163 | 4024 | 6.0 L (6.5 qt) |
| CD3029TF180 | 4023 | 9.0 L (9.5 qt) |
| | 4024 | 6.0 L (6.5 qt) |
| | 4026 | 8.5 L (9.0 qt) |
| | 4033 | 8.0 L (8.5 qt) |
| CD3029TF270 | 4006 | 8.0 L (8.5 qt) |
| | 4023 | 9.0 L (9.5 qt) |
| | 4025 | 8.0 L (8.5 qt) |
| | 4026 | 8.5 L (9.0 qt) |
| PE3029DF120 | 4004, 4005 | 6.0 L (6.5 qt) |
| | 4006 | 8.0 L (8.5 qt) |
| | 4022 | 7.0 L (7.5 qt) |
| PE3029DF150 | 4004 | 6.0 L (6.5 qt) |
| PE3029TF120 | 4025 | 8.0 L (8.5 qt) |
| PE3029TF150 | 4006, 4025 | 8.0 L (8.5 qt) |
| | 4023 | 9.0 L (9.5 qt) |
| PE3029TF270 | 4006 | 8.0 L (8.5 qt) |
| | 4023 | 9.0 L (9.5 qt) |
| | 4025 | 8.0 L (8.5 qt) |
| | 4026 | 8.5 L (9.0 qt) |


Crankcase oil capacity may vary slightly from amount shown. ALWAYS fill crankcase to full mark or within

crosshatch, or between arrows on dipstick, whichever is present. DO NOT overfill.

RG, RG34710, 5100 -19-18FEB03-3/3

Unified Inch Bolt and Screw Torque Values

TS1671 –UN-01MAY03



| Bolt or Screw | SAE Grade 1 | | | | SAE Grade 2 ^a | | | | SAE Grade 5, 5.1 or 5.2 | | | | SAE Grade 8 or 8.2 | | | |
|------------------|-------------------------|-------|------------------|-------|--------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|
| | Lubricated ^b | | Dry ^c | | Lubricated ^b | | Dry ^c | | Lubricated ^b | | Dry ^c | | Lubricated ^b | | Dry ^c | |
| Size | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in |
| 1/4 | 3.7 | 33 | 4.7 | 42 | 6 | 53 | 7.5 | 66 | 9.5 | 84 | 12 | 106 | 13.5 | 120 | 17 | 150 |
| | | | | | | | | | | | | | N•m | lb-ft | N•m | lb-ft |
| 5/16 | 7.7 | 68 | 9.8 | 86 | 12 | 106 | 15.5 | 137 | 19.5 | 172 | 25 | 221 | 28 | 20.5 | 35 | 26 |
| | | | | | | | | | N•m | lb-ft | N•m | lb-ft | | | | |
| 3/8 | 13.5 | 120 | 17.5 | 155 | 22 | 194 | 27 | 240 | 35 | 26 | 44 | 32.5 | 49 | 36 | 63 | 46 |
| | | | N•m | lb-ft | N•m | lb-ft | N•m | lb-ft | | | | | | | | |
| 7/16 | 22 | 194 | 28 | 20.5 | 35 | 26 | 44 | 32.5 | 56 | 41 | 70 | 52 | 80 | 59 | 100 | 74 |
| | N•m | lb-ft | | | | | | | | | | | | | | |
| 1/2 | 34 | 25 | 42 | 31 | 53 | 39 | 67 | 49 | 85 | 63 | 110 | 80 | 120 | 88 | 155 | 115 |
| 9/16 | 48 | 35.5 | 60 | 45 | 76 | 56 | 95 | 70 | 125 | 92 | 155 | 115 | 175 | 130 | 220 | 165 |
| 5/8 | 67 | 49 | 85 | 63 | 105 | 77 | 135 | 100 | 170 | 125 | 215 | 160 | 240 | 175 | 305 | 225 |
| 3/4 | 120 | 88 | 150 | 110 | 190 | 140 | 240 | 175 | 300 | 220 | 380 | 280 | 425 | 315 | 540 | 400 |
| 7/8 | 190 | 140 | 240 | 175 | 190 | 140 | 240 | 175 | 490 | 360 | 615 | 455 | 690 | 510 | 870 | 640 |
| 1 | 285 | 210 | 360 | 265 | 285 | 210 | 360 | 265 | 730 | 540 | 920 | 680 | 1030 | 760 | 1300 | 960 |
| 1-1/8 | 400 | 300 | 510 | 375 | 400 | 300 | 510 | 375 | 910 | 670 | 1150 | 850 | 1450 | 1075 | 1850 | 1350 |
| 1-1/4 | 570 | 420 | 725 | 535 | 570 | 420 | 725 | 535 | 1280 | 945 | 1630 | 1200 | 2050 | 1500 | 2600 | 1920 |
| 1-3/8 | 750 | 550 | 950 | 700 | 750 | 550 | 950 | 700 | 1700 | 1250 | 2140 | 1580 | 2700 | 2000 | 3400 | 2500 |
| 1-1/2 | 990 | 730 | 1250 | 930 | 990 | 730 | 1250 | 930 | 2250 | 1650 | 2850 | 2100 | 3600 | 2650 | 4550 | 3350 |

Torque values listed are for general use only, based on the strength of the bolt or screw. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For plastic insert or crimped steel type lock nuts, for stainless steel fasteners, or for nuts on U-bolts, see the tightening instructions for the specific application. Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.


Replace fasteners with the same or higher grade. If higher grade fasteners are used, tighten these to the strength of the original. Make sure fastener threads are clean and that you properly start thread engagement. When possible, lubricate plain or zinc plated fasteners other than lock nuts, wheel bolts or wheel nuts, unless different instructions are given for the specific application.

^aGrade 2 applies for hex cap screws (not hex bolts) up to 6. in. (152 mm) long. Grade 1 applies for hex cap screws over 6 in. (152 mm) long, and for all other types of bolts and screws of any length.

^b"Lubricated" means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or 7/8 in. and larger fasteners with JDM F13C zinc flake coating.

^c"Dry" means plain or zinc plated without any lubrication, or 1/4 to 3/4 in. fasteners with JDM F13B zinc flake coating.

Metric Bolt and Screw Torque Values



TS1670 -UN-01MAY03

| Bolt or Screw | Class 4.8 | | | | Class 8.8 or 9.8 | | | | Class 10.9 | | | | Class 12.9 | | | |
|------------------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|
| | Lubricated ^a | | Dry ^b | | Lubricated ^a | | Dry ^b | | Lubricated ^a | | Dry ^b | | Lubricated ^a | | Dry ^b | |
| Size | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in | N•m | lb-in |
| M6 | 4.7 | 42 | 6 | 53 | 8.9 | 79 | 11.3 | 100 | 13 | 115 | 16.5 | 146 | 15.5 | 137 | 19.5 | 172 |
| | | | | | | | | | N•m | lb-ft | N•m | lb-ft | N•m | lb-ft | N•m | lb-ft |
| M8 | 11.5 | 102 | 14.5 | 128 | 22 | 194 | 27.5 | 243 | 32 | 23.5 | 40 | 29.5 | 37 | 27.5 | 47 | 35 |
| | | | N•m | lb-ft | N•m | lb-ft | N•m | lb-ft | | | | | | | | |
| M10 | 23 | 204 | 29 | 21 | 43 | 32 | 55 | 40 | 63 | 46 | 80 | 59 | 75 | 55 | 95 | 70 |
| | N•m | lb-ft | | | | | | | | | | | | | | |
| M12 | 40 | 29.5 | 50 | 37 | 75 | 55 | 95 | 70 | 110 | 80 | 140 | 105 | 130 | 95 | 165 | 120 |
| M14 | 63 | 46 | 80 | 59 | 120 | 88 | 150 | 110 | 175 | 130 | 220 | 165 | 205 | 150 | 260 | 190 |
| M16 | 100 | 74 | 125 | 92 | 190 | 140 | 240 | 175 | 275 | 200 | 350 | 255 | 320 | 235 | 400 | 300 |
| M18 | 135 | 100 | 170 | 125 | 265 | 195 | 330 | 245 | 375 | 275 | 475 | 350 | 440 | 325 | 560 | 410 |
| M20 | 190 | 140 | 245 | 180 | 375 | 275 | 475 | 350 | 530 | 390 | 675 | 500 | 625 | 460 | 790 | 580 |
| M22 | 265 | 195 | 330 | 245 | 510 | 375 | 650 | 480 | 725 | 535 | 920 | 680 | 850 | 625 | 1080 | 800 |
| M24 | 330 | 245 | 425 | 315 | 650 | 480 | 820 | 600 | 920 | 680 | 1150 | 850 | 1080 | 800 | 1350 | 1000 |
| M27 | 490 | 360 | 625 | 460 | 950 | 700 | 1200 | 885 | 1350 | 1000 | 1700 | 1250 | 1580 | 1160 | 2000 | 1475 |
| M30 | 660 | 490 | 850 | 625 | 1290 | 950 | 1630 | 1200 | 1850 | 1350 | 2300 | 1700 | 2140 | 1580 | 2700 | 2000 |
| M33 | 900 | 665 | 1150 | 850 | 1750 | 1300 | 2200 | 1625 | 2500 | 1850 | 3150 | 2325 | 2900 | 2150 | 3700 | 2730 |
| M36 | 1150 | 850 | 1450 | 1075 | 2250 | 1650 | 2850 | 2100 | 3200 | 2350 | 4050 | 3000 | 3750 | 2770 | 4750 | 3500 |

Torque values listed are for general use only, based on the strength of the bolt or screw. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For stainless steel fasteners or for nuts on U-bolts, see the tightening instructions for the specific application. Tighten plastic insert or crimped steel type lock nuts by turning the nut to the dry torque shown in the chart, unless different instructions are given for the specific application.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class. Replace fasteners with the same or higher property class. If higher property class fasteners are used, tighten these to the strength of the original. Make sure fastener threads are clean and that you properly start thread engagement. When possible, lubricate plain or zinc plated fasteners other than lock nuts, wheel bolts or wheel nuts, unless different instructions are given for the specific application.

^a“Lubricated” means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or M20 and larger fasteners with JDM F13C zinc flake coating.

^b“Dry” means plain or zinc plated without any lubrication, or M6 to M18 fasteners with JDM F13B zinc flake coating.

Lubrication and Maintenance Records

Using Lubrication And Maintenance Records

Refer to specific Lubrication and Maintenance Section for detailed service procedures.

1. Keep a record of the number of hours you operate your engine by regular observation of hour meter.
2. Check your record regularly to learn when your engine needs service.
3. DO ALL the services within an interval section. Write the number of hours (from your service records) and the date in the spaces provided. For a complete listing of all items to be performed and the service intervals required, refer to the quick-reference chart near the front of the Lubrication and Maintenance Section.

IMPORTANT: The service recommendations covered in this manual are for the accessories that are provided by John Deere. Follow manufacturer's service recommendations for servicing engine driven equipment not supplied by Deere.

RG, RG34710, 5103 -19-30JAN98-1/1

Daily (Prestarting) Service

Check engine oil level.

Check coolant level.

Lubricate PTO release bearing.

Check air cleaner dust unloader valve and air restriction indicator, if equipped.

Visual walkaround inspection.

Check fuel filter.

RG, RG34710, 5104 -19-30JAN98-1/1

250 Hour/6 Month Service

Service fire extinguisher.

Lubricate PTO clutch shaft bearings.

Service battery.

All except 3029TF270 engines: Change engine oil and filter.¹

Check fan and alternator belt tension.

Check PTO clutch adjustment.

Check engine mounts.

| | | | | | | | | | |
|-------|--|--|--|--|--|--|--|--|--|
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |

¹If John Deere PLUS-50 or E7/E6/E5/E4 oil is used along with the specified John Deere oil filter, the oil change interval may be extended by 50 percent to 375 hours.

500 Hour/12 Month Service

3029TF270 engines only: Change engine oil and filter.¹

Replace fuel filter/bleed system.

Check engine ground connection.

Check cooling system.

Lubricate PTO clutch internal levers and linkage.

Coolant solution analysis - add SCAs as needed.

Clean crankcase vent tube.

Pressure test cooling system.

Check air intake hoses, connections, and system.

Check and adjust engine speeds.

| | | | | | | | | | |
|-------|--|--|--|--|--|--|--|--|--|
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |

¹If John Deere PLUS-50 or ACEA-E7/E6/E5/E4 oil and the specified John Deere oil filter are NOT used, the oil change interval is reduced to 250 hours.

2000 Hour/24 Month Service

Adjust variable speed (droop) on generator set engines.

Check and adjust engine valve clearance.

Flush and refill cooling system.¹

Test thermostat opening temperature.

| | | | | | | | | | |
|-------|--|--|--|--|--|--|--|--|--|
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |

¹If John Deere COOL-GARD is used, the flushing interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used, and the coolant is tested annually AND additives are replenished by adding supplemental coolant additives (SCA's), the flushing interval may be extended to 5000 hours or 60 months, whichever occurs first.

Service As Required

Add coolant.

Bleed fuel system.

Replace air cleaner elements.

Replace belts.

Check fuses.


Inspect PTO clutch. (If equipped.)

| | | | | | | | | | |
|-------|--|--|--|--|--|--|--|--|--|
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |
| Hours | | | | | | | | | |
| Date | | | | | | | | | |

RG, RG34710, 5110 -19-13FEB03-1/1

Emission System Warranty

Emissions Control System Certification Label

 **CAUTION: Statutes providing severe penalties for tampering with emissions controls may apply at the user's location.**

The emissions warranty described below applies only to those engines marketed by John Deere that have been certified by the United States Environmental Protection Agency (EPA) and/or California Air Resources Board (CARB); and used in the United States and Canada in non-road mobile (self-propelled or portable/transportable¹) equipment. The presence of an emissions label like the one shown signifies that the engine has been certified with the EPA and/or CARB. The EPA and CARB warranties only apply to new engines having the certification label affixed to the engine and sold as stated above in the geographic areas. The presence of an EU number in the third line of the label signifies that the engine has been certified with the European Union countries per Directive 97/68/EC. The emissions warranty does not apply to the EU countries.

NOTE: *The hp/kW rating on the engine emissions certification label specifies the gross engine hp/kW, which is flywheel power without fan. In most applications this will not be the same rating as the advertised vehicle hp/kW rating.*



Emissions Label

¹Equipment moved at least once every 12 months.

U.S. Emissions Control Warranty Statement (*United States Only*)

Emissions control-related parts and components are warranted by John Deere for five years or 3000 hours of operation, whichever occurs first. John Deere further warrants that the engine covered by this warranty was designed, built, and equipped so as to conform at the time of sale with all U.S. emissions standards at the time of manufacture, and that it is free of defects in materials and workmanship which would cause it not to meet these standards within the period of five years or 3000 hours of operation, whichever occurs first.

Warranties stated in this manual refer only to emissions-related parts and components of your engine. The complete engine warranty, less emissions-related parts and components, is provided separately as the "John Deere New Off-Highway Engine Warranty".

RG, RG34710, 5112 -19-30JAN98-1/1

John Deere Service Literature Available

Technical Information

Technical information can be purchased from John Deere. Some of this information is available in electronic media, such as CD-ROM disks, and in printed form. There are many ways to order. Contact your John Deere dealer. Call **1-800-522-7448** to order using a credit card. Search online from <http://www.JohnDeere.com>. Please have available the model number, serial number, and name of the product.

Available information includes:

- **PARTS CATALOGS** list service parts available for your machine with exploded view illustrations to help you identify the correct parts. It is also useful in assembling and disassembling.
- **OPERATOR'S MANUALS** providing safety, operating, maintenance, and service information. These manuals and safety signs on your machine may also be available in other languages.
- **OPERATOR'S VIDEO TAPES** showing highlights of safety, operating, maintenance, and service information. These tapes may be available in multiple languages and formats.
- **TECHNICAL MANUALS** outlining service information for your machine. Included are specifications, illustrated assembly and disassembly procedures, hydraulic oil flow diagrams, and wiring diagrams. Some products have separate manuals for repair and diagnostic information. Some components, such as engines, are available in separate component technical manuals
- **FUNDAMENTAL MANUALS** detailing basic information regardless of manufacturer:
 - Agricultural Primer series covers technology in farming and ranching, featuring subjects like computers, the Internet, and precision farming.
 - Farm Business Management series examines "real-world" problems and offers practical solutions in the areas of marketing, financing, equipment selection, and compliance.
 - Fundamentals of Services manuals show you how to repair and maintain off-road equipment.



TS189 -UN-17JAN89



TS191 -UN-02DEC88



TS224 -UN-17JAN89



TS1663 -UN-10OCT97

Continued on next page

DX.SERV.LIT -19-31JUL03-1/2

- Fundamentals of Machine Operation manuals explain machine capacities and adjustments, how to improve machine performance, and how to eliminate unnecessary field operations.

Index

| | Page | | Page | | |
|--|-------------|--|------------|---------------------------|------|
| A | | | | | |
| Acid burns | 30-2 | Cooling system | | | |
| Air cleaner | | Adding coolant | 45-2 | | |
| Cleaning element | 45-8 | Check | 35-8 | | |
| Element storage | 45-9 | Flush and refill | 40-4 | | |
| Inspect element. | 45-8 | Pressure test. | 35-12 | | |
| Air filter, replace | 45-6 | Pressure test radiator cap. | 35-12 | | |
| Air filter, service | 45-8 | Troubleshooting | 50-16 | | |
| Air intake system | | Crankcase vent tube, clean | 35-4 | | |
| Troubleshooting | 50-18 | | | | |
| Air intake system, check. | 35-5 | D | | | |
| Alternator belt. | 30-6 | Diesel engine oil. | 10-7 | | |
| Ammeter. | 15-1 | Diesel fuel | 10-1, 10-3 | | |
| Auxiliary gear drive, limitations | 15-9 | | | | |
| Aviation fuels | 10-4 | E | | | |
| B | | | | | |
| Battery | | Electrical system diagram (North American) | 50-2 | | |
| Acid burns. | 30-2 | Electrical system troubleshooting | 50-12 | | |
| Capacities. | 30-2 | Emissions | | | |
| Explosion | 30-2 | EPA statement | 70-2 | | |
| Service | 30-2 | Warranty label. | 70-1 | | |
| Belts, fan and alternator | | Engine | | | |
| Checking tension | 30-6 | Add coolant. | 45-2 | | |
| Replacing | 30-6, 45-9 | Break-in | 15-12 | | |
| Bleeding fuel system | 45-3 | Idling. | 15-18 | | |
| Break-in engine oil | 10-6 | Operation | 15-15 | | |
| Break-in, engine. | 15-12 | Speed, check and adjust. | 35-14 | | |
| Burner fuels | 10-4 | Starting | 15-9 | | |
| | | Stopping | 15-19 | | |
| C | | | | Troubleshooting | 50-1 |
| Chart, service interval, prime power | 20-3 | Valve clearance, check and adjust | 40-2 | | |
| Chart, service interval, standby power | 20-5 | Warming | 15-17 | | |
| Checking fuses. | 45-11 | Engine coolant | | | |
| Clutch adjustment. | 30-9 | Disposing of | 10-16 | | |
| Cold weather aids. | 15-16 | Engine electrical system | | | |
| Coolant | | Troubleshooting | 50-12 | | |
| Adding | 45-2 | Wiring diagram (North American) | 50-2 | | |
| Additional information | 10-13 | Engine mounts | | | |
| Diesel engine | 10-11 | Checking. | 30-10 | | |
| Disposing | 10-16 | Engine oil | | | |
| Replenishing supplemental additives. | 35-10 | Break-In | 10-6 | | |
| Supplemental additives | 10-15 | Change (All except 3029TF270 engines) | 30-4 | | |
| Testing | 10-14, 35-9 | Change (3029TF270 engines only). | 35-1 | | |
| Warm temperature climates | 10-15 | Diesel | 10-7 | | |
| Coolant temperature gauge | 15-1 | Oil filter change (All except 3029TF270 engines) | 30-4 | | |
| | | Oil filter change (3029TF270 engines only). . . | 35-1 | | |
| | | Engine speed, changing. | 15-18 | | |
| | | Droop | 40-1 | | |

| F | Page | L | Page |
|--|-------------|--|-------------|
| Fan belts | 30-6 | Lubricant | |
| Filter, replace | | Mixing | 10-8 |
| Air | 45-6 | Storage | 10-10 |
| Fuel | 35-6 | Lubrication and maintenance | |
| Oil (All except 3029TF270 engines) | 30-4 | Daily | 25-1 |
| Oil (3029TF270 engines only) | 35-1 | Service interval chart - prime power | 20-3 |
| Filters, air, service | 45-8 | Service interval chart - standby power | 20-5 |
| Fire extinguisher, service | 30-1 | 2000 hour/24month | 40-1 |
| Fuel | | 250 hour/6month | 30-1 |
| Aviation | 10-4 | 500 hour/12month | 35-1 |
| Burner | 10-4 | Lubrication system | |
| Diesel | 10-1, 10-3 | Troubleshooting | 50-14 |
| Handling and storing | 10-2 | Lubrlicity of diesel fuel | 10-1 |
| Jet | 10-4 | | |
| Kerosene | 10-4 | M | |
| Lubrlicity | 10-1 | Maintenance, periodic | |
| Fuel filter | | Daily | 25-1 |
| Check | 25-5 | 2000 hour/24 month | 40-1 |
| Replace | 35-6 | 250 hour/6 month | 30-1 |
| Fuel system | | 500 hour/12 month | 35-1 |
| Bleeding | 45-3 | Metric torque values | 65-1 |
| G | | Mixing lubricants | 10-8 |
| Gauge panel | | Mounts, engine | |
| North American, AEZ, VDO | 15-1 | Checking | 30-10 |
| Grease | | | |
| Extreme pressure and multipurpose | 10-10 | O | |
| H | | Oil | |
| Hour meter | 15-1 | Checking and adding | 25-1 |
| I | | Fill quantity | 60-7 |
| Idling engine | 15-18 | Filter, change (All except 3029TF270 engines) | 30-4 |
| Instrument panel | | Filter, change (3029TF270 engines only) | 35-1 |
| North American, AEZ, VDO | 15-1 | Refilling crankcase (All except 3029TF270 engines) | 30-4 |
| Intake and exhaust system | | Refilling crankcase (3029TF270 engines only) | 35-1 |
| Troubleshooting | 50-18 | Specifications for dipstick options | 60-7 |
| J | | Oil pressure gauge | 15-1 |
| Jet fuels | 10-4 | Operating engine | |
| | | Break-in | 15-12 |
| | | Cold weather | 15-16 |
| | | Normal operation | 15-15 |

Page

Page

P

Lubrication system 50-14
 Turbocharger 50-18

Power take-off (PTO)
 Clutch, lubricate 45-10
 Levers and linkages, lubricate 35-4
 Shaft bearings, lubricate 30-1
 PTO clutch adjustment 30-9

V

Valve clearance, check and adjust 40-2

S

W

Service
 Fire extinguisher 30-1
 Intervals - prime power 20-3
 Intervals - standby power 20-5
 Specifications
 Engine crankcase oil fill 60-7
 Engine power and speed - emission non-certified engines 60-5
 Engine power and speed- Tier I emission certified engines 60-3
 Engine power and speed- Tier II emission certified engines 60-4
 General OEM 60-1
 Torque values, metric 65-1
 Standby power units 15-9
 Starting engine 15-9
 Stopping engine 15-19
 Storage
 Air cleaner element 45-9
 Guidelines 55-1
 Long term 55-2
 Removing from 55-3
 Storing fuel 10-2
 Storing lubricants 10-10
 Supplemental coolant additives
 Replenishing 35-10

Warming engine 15-17
 Warranty
 Emission system 70-1
 EPA emissions statement 70-2
 Wiring diagram
 North American 50-2

T

Tachometer 15-1
 Temperature gauge (coolant) 15-1
 Thermostat, test opening temperature 40-7
 Torque values
 Metric 65-1
 Troubleshooting
 Air intake 50-18
 Cooling 50-16
 Electrical 50-12
 General 50-1

